

UM-UE01001

Y-UE01001 说明书 128g双铜 单黑双面印刷

140\*100mm 风琴折 折后70\*100mm


Y-UE01001  
USB1.1 Extension Over RJ45 (Up to 60M)  
**User Manual**



**Product Overview**

Thank you for choosing UNITEK product, Y-UE01001 is USB1.1 Extension over RJ45. It adopts premium chipset, with Cat5, Cat5e or Cat6 RJ45 LAN cable, it can extend up to 60M. Applicable for all usage platforms, supports plug and play.

**Product Schematic Diagram**



**Installation**

1. Connect both RJ45 ports (Transmitter and Receiver) by Cat5/Cat5e/Cat6 RJ45 LAN cable.
2. Connect Transmitter's USB Type-A (Male) connector to computer.
3. Connect your USB devices to the hub (Receiver).

**Caution**

1. Please remove USB devices properly. Click 'Safety Remove Hardware and Eject Media' before removing the devices from computer.
2. Transmission speed will be different depend on device.
3. Please use good quality/premium Cat5/Cat5e/Cat6 RJ45 LAN cable which is not exceed 60m.


Y-UE01001  
USB1.1 60米延长集线器  
**使用向导**



**产品简介**

尊敬的客户,感谢您选用本公司USB延长线类产品,USB 延长线采用业界高性能稳定性强的主控芯片,通过RJ45接口采用Cat5/Cat5e/Cat6网线连接,高保真传输延长距离达到60米;即插即用,免驱使用。

**产品外观示意图**



**安装指南**

1. 采用Cat5/Cat5e/Cat6 RJ45 网线将上行和下行RJ45接口连接
2. 直接将产品的上行公头连接到电脑。
3. 将USB设备插入下行端口开始使用。

**注意事项**

1. USB 设备虽然支持热插拔,但是在使用 U盘、移动硬盘等存储设备时尽量先“安全移除设备”后再拔出设备,以免造成数据丢失。
2. 由于 USB 信号长距离延长,USB 信号会有所衰减,根据所连接的设备不同,传输速度会有差异。
3. 建议选用优质的 Cat5 / Cat5e / Cat6 RJ45 网线连接,最大延长距离不要超过 60米。