


## Versailles – User manual



### **Mechanical movement**

The Versailles model has a mechanical movement. The power reserve is approximately 48 hours. Power reserve refers to the available energy stored in a watch's mainspring. While the watch runs, the spring gradually unwinds, until all the power is spent and the watch stops or is wound up again.

### **Winding**

Before using the watch for the first time or if you have not worn the watch for more than 48 hours, it must be wound up. To wind the watch, turn the crown (K) approximately 50 turns clockwise (upwards towards 12 o'clock) without pulling out the crown (K) first. You will hear a soft sound of the winding mechanism when winding the watch. Please always turn the crown (K) clockwise to wind it up. Turn the crown (K) until it cannot be turned anymore. You will feel resistance and the crown (K) will not turn any further. Do not continue to turn the crown when you feel resistance and the watch is fully wound. We recommend winding the watch fully every morning.

### **Setting the time**

You should wind your watch first before you set the time. After winding, gently pull out the crown (K). Turn the crown (K) so that the hands turn clockwise. When you have set the time correctly, push the crown (K) firmly back against the case to its original position.