BAITING INSTRUCTIONS ROOF CAT

Use a crunchy and thick peanut butter.

Pill the cup two-thirds full, a little showing on the rim is ideal as a visual cue.



Add a couple of drops of vanilla essence and mix in thoroughly.


For a new set add a little bait on the hatch rim, as shown. This helps to overcome the rodents instinctive wariness of an unfamiliar object in their environment. Once your trap has been visited this is no longer required.

MODE SETTING INSTRUCTIONS ROOF CAT

① SET TRAP

① ⇒ ⇒

2 SENSITIVE



3 UNSET TRAP



You must have your trap in this mode to set.

Move the mode switch to the set position ① as shown. This is standard rat mode, you can leave trap set in this mode when you are getting familiar with your Roof Cat. To make the trap more sensitive move the red mode switch to the position as shown. This setting enables the wariest of rats and small mice to be caught. Be careful as in this setting the slightest bump can set off your trap.

Moving the red mode switch towards unset mode as shown, will unset your trap.

Warning keep fingers clear! We recommend you control the un-setting of your trap using the safety set lever.