



7002B FRONT SHELF ASSEMBLY

1. Use a screwdriver to remove the screws and washers that have been assembled in the grill chamber.
2. Insert bolts through the washer and front shelf bracket in order into the grill chamber, as shown.
3. Insert the step screw through the front shelf and front shelf bracket, then tighten it.