7. How to control the function of device?



1.Click [the device] to be controlled to enter the control page. 2.Control the grill temperature between 160 and 450°F (71-232°C).
3.The temperature unit °F displayed can be switched to °C.

4. You can check the current temperature of the grill.5. The alarm temperature of the probe can be set. When the probe temperature is greater than or equal to the alarm temperature, an alarm

box will pop up at the top of the page. 6. The grill can be turned off on the app, and the grill cannot be

remotely turned on from the app for security reasons. 7.Click [] in the upper right corner to view the specific

- information of this device. Tip: When controlling the device, you need to turn on Bluetooth or
- WiFi, and keep it as close to the grill as possible to avoid failure. Please refer to the product manual for details.

1.How to download [Z GRILLS]?

8. How to share a device?





2. How to register a new account?



1.Open the APP on you mobile and enter the login page, then click

[sign up]. 2.Sign up with your E-mail ID or mobile phone number. a.Enter your mobile phone number, and select the correct

country/region code (Note: only for USA-other countries don't support the use of device). Then click [send verification code].

b.Enter your E-mail ID, and then click [send verification code].

3. Enter verification code you received and then set a password. 4.If you have signed up an account successfully, you can log in your account automatically to use this APP.



What is the Scene?

You can control the status of a group of devices with one click. For example, you can control the switch of multiple devices by clicking a button.

How to add scene?

1.On the scene page, click [+] in the upper right corner or [Add

scene]. 2.Select the device and its specific functions that need to be executed. You can add multiple groups, and edit their names. 3.Click [ok] and save, you can see the saved scenes in the scene list. 4.Click the switch corresponding to the scene in the scene list to execute the set scene function.

3. How to edit/view personal information?



1.Click [Me-Account Settings], and you can edit/view personal information.

2. You can change your personal avatar and set a new nickname. 3. You can view the account and the location of the account. 4. You can modify the password or delete the account. 5. You can log out of your account or log in.

1. You can download and install the APP by searching the name of App [Z GRILLS] in the [App Store] or [Google Play].

2.After downloading, please review the [User Agreement] and [Privacy Policy] carefully and acknowlewdge them.

	₿10100% ■ 2:15
nt Settin	gs
	•
	12345677 >
	15751004165
	United States of America
	>
	2
og out	

10.What is automation?



What is automation?

When the conditions you set are met, it can automatically trigger the linkage of other devices. For example, power on a device is accompanied by the power page of another device.

How to add automation?

1.On the automation page, click [+]in the upper right corner or [Add]. 2.First add the conditions, and you can choose the time, period or the status of a certain device.

- 3. Then add the device actions that need to be executed. Click [OK] and save, and you can see the saved automation in the automation list. 4. Click the switch corresponding to the automation in the automation
- list to execute the set automation function.

11. How to deal with usage issues?

030	≵ ፤⊡ ፤ 100% 🗪 2:14	1	2	∦ ∎≣ ∎ 2:29
12345677	0	<	FAQ	
15751004165		Issue Type		
G Family Management	>	APP Issue		
Amessage Center	>	Device Issue	PG-9002C	
Feedback	>			
Device Sharing	>			
7 FAQ	>			
(i) About	>			
<u> </u>	0			
Home Intelligence	O Me			

1.If you encounter app or device usage problems, you can choose to view the related problems in [Me-FAQ].

2.Need additional assistance? Please contact the after-sales service.

4. How to cancel the account?

020

rofile Picture

nange Passwor

Account

≵ i ⊡ i 100% 💌 i 2:15	D 🗟 🖸	∦ I ∎100% m 2:17			
Settings	< Delete A	< Delete Account			
ø	After deleting the ac				
12345677 >		mobile number, email address, etc. will be			
15751004165	In addition, you will no longer be able to use all devices that you bound through				
United States of America	this account. The above operation	n is irreversible. If			
>	you still want to delete Next.	your account, tap			
2					
out					
	Nex	t			
]	L				

1.You can delete the account at [Me-Account Settings-Delete Account].

2.After the account is deleted, all information will be erased. This operation is not reversible, please operate with caution.



1. You can modify the password at [Me-Account Settings-Change Password]. Then click [send verification code].

2.Enter the verification code, and then enter the new password. Click [Confirm]

6.How to add a WiFi Router?



1.Keep the phone connected to WiFi and turn on Bluetooth. 2.Click [+] in the upper right corner of the homepage. Device will be automatically added by default (you also can choose to add manually).

3. The device enters the state of network distribution. 4.After the device is searched successfully, enter the corresponding WiFi password. Click [Next] 5. You can see the added device in the device list, and you can

control the device by entering the control page. configuration.

[Z GRILLS] App user manual



Note: When configuring the network, try to keep the mobile

phone, device and router close to avoid failure of the network

L			

