

Turn ON Instruction (450B, 7002C, 7002C2E, 700D3, 700D4E)

After you plug it in, please press the button to start and then turn the dial to Smoke. To turn the grill on, it requires a short press. If the button is depressed too long, the grill will not turn on. To turn it off, it requires a long press.

