

**SCORE
BAND®**

PULSE

Laser Rangefinder for Golf



ScoreBand PULSE Rangefinder
Model #: SB-PULSE
www.ScoreBand.net



Before using ScoreBand PULSE, please read this manual thoroughly to prevent any confusion during play.

GET FAMILIAR: Buttons & Components



2


LCD DISPLAY




3

GET STARTED

1. Look into the eyepiece and press the Open button. ScoreBand PULSE will power-on and the measurement display will appear.



While distance measurement is in progress, four diagonal search lines appear around center of the crosshair. Once distance is locked-in and displayed, the search lines will disappear.



4

2. Rotate the eyepiece to the left or right to fine-tune the focus to your eye.




3. Press the Mode button to switch between Flag-Lock Mode and General Mode. Flag-Lock Mode enables improved distance measurement to the flagstick by blocking out background objects. General Mode will measure all objects in path with equal priority.




5

4. Press and Hold the Mode button to switch measurement unit between Meter (m) and Yards (Yd).



5. Power-off: Unit will automatically power off after 30 seconds without use.

6. When low battery indicator appears  battery needs to be changed.

NOTES

1. The measuring range of the rangefinder is influenced by the angle between the laser and the target. The measuring distance is better when aiming laser at a smooth surface, bright color, large surface and square angle.
2. Rangefinder accuracy can be affected when the battery is low. When low battery indicator appears, replace battery for best performance.
3. Do not touch the glass lens areas, or disassemble. The rangefinder has been

6

aligned and assembled using precise technical equipment.

4. Keep device in a cool, dry place and avoid dust, direct sunlight and extreme high/low temperatures.

5. To prevent damage to internal photosensitive components, do not transmit laser towards the sun or other strong light sources.

6. Please contact us directly if you experience any problems with your rangefinder.

PRODUCT SPECIFICATIONS

Measure Range: 5 to 400 Yards

Objective Lens: 24mm

Magnification: 6x

Field of View: 7°

Exit Pupil Diameter: 3.8mm

Diopter Adjust Range: +/- 4

Working Temperature: 0° to 120°F

Accuracy: +/- 1 Yard

Battery Type: CR2 (3 Volt)

Low Battery Indicator: Yes

Flag-Lock: Yes

Range to Flag: 5 to 250 Yards

Weight: 150g

Dimensions: 103 x 72 x 40mm

7

WARRANTY

ScoreBand PULSE is covered by a limited one-year warranty. Go online to register your device for warranty and to view full details at: www.scoreband.net/products/scoreband-pulse

ONESSED

PO Box 20171

Charleston, SC 29413

www.scoreband.net

Phone: 888.722.0444

Email: support@scoreband.net

PLAY WELL!

8