



Gemini IRIS Rear Light

180 Lumens

Gemini
LIGHTS

Congratulations on your purchase of a Gemini IRIS Rear Light!
Please take a moment to get to know your new light.

ONE YEAR WARRANTY

Your purchase is protected by Gemini Lights with a one year warranty covering any defects in material and workmanship.

MOUNTING

The IRIS Rear Light can be attached to a backpack with a clip mount or a seat post with an o-ring. The two mounts are swappable by using the 3mm hex key. To access the screw port on the seat post mount, peel back the adhesive rubber pad.



LIGHT OPERATION

To switch the light ON, press the  button.






To switch the light OFF, press the  button for 1s.

To cycle through the four modes, press the  button repeatedly.

| | | |
|--------------|------------|----------------|
| Flash (Low) | 10 Lumens | 11 hrs runtime |
| Flash (High) | 100 Lumens | 2 hrs runtime |
| Pulse (Low) | 10 Lumens | 22 hrs runtime |
| Pulse (High) | 100 Lumens | 4 hrs runtime |




LED INDICATOR

The  button provides feedback on the status of your light.

-  Green: 100-50% battery charge
-  Amber: 50-25% battery charge
-  Red: 25-10% battery charge
-  Flashing Red: 10-0% battery charge remaining
-  Flashing Amber: Light is in programming mode

PROGRAMMING MODES

There are five brightness levels available to save as the default.

1. Navigate to the selected mode and press the  button for 3s. The light will enter programming mode and output 10L brightness.
2. With each click of the  button, the light cycles through the 5 different brightness levels: 10L - 30L - 50L - 100L - 180L
3. To save the brightness level and exit programming mode, press the  button for 3s. The light will turn off and on again to confirm the change.

FACTORY RESET

To reset to factory default settings, press the  button for 10s. Three quick flashes will confirm the change.

USB CHARGING

The IRIS Rear Light comes with a built-in USB rechargeable battery. Remove the rubber cap to access the USB port.




Flashing Amber: Battery is charging



Green: Battery is full

A full charge will take 2 hours to complete.

LOW BATTERY WARNING

When the battery charge reaches a very low level, the  button will flash red and the light will automatically dim to low power to conserve energy.

FOR MORE INFORMATION

Please visit our website for more detailed information about product usage, warranty and battery care.

Contact Information

To view our FAQ go to our website:

<http://gemini-lights.com/support/faq>

For any enquiries please contact us below:

<http://gemini-lights.com/contact>

Or you can email us directly at:

Product Information: info@gemini-lights.com

Customer Support: support@gemini-lights.com