


Rotary Airer 30/40/50M

KCT

GLS101/102/103


Parts Included:



Imported by:
KCT Leisure
Glebe Farm, Old London Road,
Copdock,
Ipswich, Suffolk,
IP83JN,
United Kingdom

Assembly

1. Carefully remove all packaging.
2. Push lower section [B] into the upper section [A].
3. Establish a suitable location for the airer, ensuring that there is sufficient space for it to rotate freely once the arms are opened [D].
4. Insert airer into the plastic ground socket.



Turning Table
Diameter - (approx)
30m: 190cm
40m: 202cm
50m: 220cm

Usage

To open, slide centre collar upwards and past the clip until it springs back into place. To close, depress the clip and carefully slide centre collar downwards to its lowest position.

Storage

When not in use, we recommend that the airer is covered and securely tied. If removing from the ground socket for storage, please ensure that the airer is covered and kept out of reach of children.

Caution!

- The rotary dryer is not a childrens toy. Be aware, children can get caught in the lines!
- Before positioning the ground spike or tube, look for a good sport for the rotary, if possible in a sunny location away from shade and out of the way of any walkways.
- Ensure there is enough space to unfold and rotate the rotary before installing.
- When not in use, always close the ground spike/tube.