

Mag-Lock with Biometric Scanner/Keypad

Admin fingerprint and user fingerprint must be different.

NOTE: We strongly recommend against relying on a single fingerprint to unlock your door. We recommend creating a backup pin or backup RFID tag and storing it in a safe place.

Enter Admin Mode

* (Red light will blink)

Master Code (factory code is 123456)

(Light will flash green and go back to flashing red)

Change Master Code

- * (Red light will blink) 123456 # (Light will flash green and go back to flashing red)
- O (Light will turn solid orange) enter new code (6 digits) # Repeat Code #
- * to exit

Add Fingerprint

Enter admin mode

- 1 (Light will turn solid orange)
 Fingerprint x3 (Long beep and green light will flash and go back to solid orange)
- # (Light will flash red)
- * to exit

Add Pin

Enter admin mode

- 1 (Light will turn solid orange) enter pin (4-6 digits... cannot be 8888)
- # (Long beep and green light will flash and go back to solid orange)
- * to exit

Add RFID Tag

Enter admin mode

1 (Light will turn solid orange)

Read RFID Tag # (Light will flash red)

* to exit

*Additional setup instructions are in the included User Manual.

Red wires connect to your power source, white and black.

Green wire, if present, should be capped.

POWER SUPPLY CONTROL

OUTPUT DC12V 3A

MODEL-K80

ACTID-24IDV

MODEL-K80

Time
POWER SUPPLY CONTROL



