Admin fingerprint and user fingerprint must be different.
NOTE: We strongly recommend against relying on a single fingerprint to unlock your door. We recommend creating a backup pin or backup RFID tag and storing it in a safe place.

Enter Admin Mode
* (Red light will blink)
Master Code (factory code is 123456)
(Light will flash green and go back to flashing red)

Change Master Code
* (Red light will blink) 123456 #
    (Light will flash green and go back to flashing red)
0 (Light will turn solid orange) enter new code (6 digits) # Repeat
    Code #
* to exit

Add Fingerprint
Enter admin mode
1 (Light will turn solid orange)
    Fingerprint x3 (Long beep and green light will flash and go back
    to solid orange)
(Light will flash red)
* to exit

Add Pin
Enter admin mode
1 (Light will turn solid orange)
    enter pin (4-6 digits... cannot be 8888)
(Long beep and green light will flash and go back to solid orange)
* to exit

Add RFID Tag
Enter admin mode
1 (Light will turn solid orange)
Read RFID Tag # (Light will flash red)
* to exit

*Additional setup instructions are in the included User Manual.

NC   NO   GND   PUSH   +12V   GND

Red   Black   Brown   Blue   Yellow

Red   Black

NOTE: Additional 18 gauge wire will be needed for installation.