




MURPHY DOOR

Mag-Lock with Push Button

Option #1

Red wires connect to your power source, white and black.

Green wire, if present, should be capped.



Option #2

Red wires connect to your power source, white and black.

Green wire, if present, should be capped.

