

QUARTZ CLOCK CHART WEIGHT TROUBLE SHOOTING

Clock will not
run

- A. Install fresh battery.
- B. Remove battery and return for service.**

Clock not
keeping proper
time

- A. Install fresh alkaline battery.
- B. Remove battery and return for service.**

**** When returning for service, be sure to remove battery. Package very carefully as Weems & Plath® can not be responsible for damage in transit. Be sure to include a note describing the problem, your phone number, mailing address and proof of purchase if claiming warranty.**

Weems & Plath®

214 EASTERN AVE. • ANNAPOLIS, MD 21403 • USA

410-263-6700 • fax 410-268-8713

www.weems-plath.com

E-mail: support@weems-plath.com