

WEEMS & PLATH® CLOCK BASES AND BOOKENDS


If Increased Bell Sound Is Required

When using this base/bookend with a Weems & Plath® Ship's Bell Clock, you will find that the felt on the base/bookend will tend to muffle the bell sound.

One or both of the following will increase bell sound

- 1) Slide the clock back in the base/bookend until the front of the bezel rests against the cradle of the base/bookend. This will expose some of the sound holes, allowing the bell sound to escape the case better.
- 2) Cut and remove approximately four (4) inches of the felt from the center of the cradle. This will cause all of the sound holes in the case to be exposed. Be sure to leave felt at each end of the cradle, as pictured below, in order to protect the clock case from hitting against the wood.

LEAVE FELT IN THIS AREA



Weems & Plath®

214 EASTERN AVE. • ANNAPOLIS, MD 21403 • USA
410-263-6700 • fax 410-268-8713 • www.weems-plath.com
E-mail: support@weems-plath.com 02/01