
HOW TO USE YOUR YARN BALL WINDER YBW-B



STEP 1.
Clamp the ball winder tightly to a sturdy table.



STEP 2.

Rotate the wire arm to the upright position. Pull it out fully until it stays up firmly. When fully pulled out, the bottom of the wire arm should stick out about 1 3/4 inches from the base.




STEP 3.

Unwind a hank of yarn and mount it on a yarn swift, or other devises (your helper's arms).



STEP 4.

Thread the yarn through the wire arm and then tightly into the cleft of the yarn holder. Be sure the yarn does not slip. Begin turning the crank on the ball winder to start winding.



ANY QUESTIONS PLEASE CONTACT US AT:

service@stanwoodimports.com sales@orientalhomegarden.com

Tel: (888) 670-5570 Copyright © Stanwood Imports / Oriental Touch LLC

