

FUCK MACHINE

Portable Battery



User Manual

English

Portable Battery Pack

If you have purchased the portable Battery Pack, your machine is no longer tethered to a wall power outlet. Using the battery pack is very simple. It connects in the same location that the power cord does. The pack itself is equipped just two functions:

1. Charging
2. Discharging

On the top of the battery pack, there are symbols/words that indicate which is which. It is important to never confuse the input/output functions as this will void the warranty and may cause damage to your battery pack, battery pack charger or sex machine. Below are some images showing how the battery pack connects to your machine.



Charging the battery pack is done using the provided cable and power adapter. A full charge should take 1-2 hours depending on battery capacity at the time of charging.

Note: Never let your battery pack fall too low in charge. This may harm the battery cells, void your warranty and likely decrease the battery pack performance and longevity. Never leave the battery pack to sit for longer than 1 month. This may again, do damage to the battery cells, void warranty and decrease performance.