

# BABY LOCK


## SEWING ACCESSORIES

### Walking Foot (BLSA-WF) Instructions


The Baby Lock Walking Foot is wonderful for fabrics that stretch or slip easily, such as velvet or corduroy. This foot has a set of feed dogs that help feed multiple layers evenly without shifting. This walking foot comes with two easily interchangeable soles, a standard sewing sole and an open toe sole.

#### To Attach Walking Foot on the Machine:

1. Raise the needle and presser foot.
2. Remove the presser foot, presser foot holder and presser foot holder screw.



3. Attach the walking foot to the presser bar with the lever surrounding the needle clamp.
4. Securely tighten the walking foot to the presser bar with the presser foot holder screw.




5. Operate the machine at low to medium speed.

Note: To use the needle threader, lower the presser foot and raise the needle to the highest position.



#### To Replace the Sole:

1. Loosen the screws 3 to 5 turns (see fig. 1) and slightly pull the sole holder out to release the sole.



2. Align the holes of the replacement sole so both sides are inserted in the holes, 2 holes on the left, and one on the right.

3. Tighten the screw.

**baby lock**

**FOR THE LOVE OF SEWING**

[www.BabyLock.com](http://www.BabyLock.com)