

## Bag Installation / Removal

1. To open the Diaper Champ™ Deluxe, press the center release button inward. Use your fingers to raise the top cover.



2. Lift the top cover allowing the bagholder to remain on the pail and ready for a bag to be inserted.



4. Make sure that the bag is flat on the bagholder surface as shown and that the top of the bag is tucked down around the outside of the bagholder. Also make sure that no part of the top of the bag extends outside the pail before closing the cover assembly. This will ensure a good seal between the two components.




5. To remove a full bag, depress the center release button and lift both the top cover and bagholder. Twist the top of the bag as shown and lift it out slowly to avoid any tears. Always use the foot at the front of the Diaper Champ<sup>TM</sup> Deluxe when opening so that the unit won't tip over.




Diaper Champ $^{\text{TM}}$  Refill is sold separately. (300 diaper capcity when using new born sized infant diapers.)




3. Using a Diaper Champ™ Refill or any 13 gallon trash bag, push the bag through the center of the bagholder down to the bottom of the pail.



## **Disassembly / Cleaning**





2. Use warm water and mild soap to clean and disinfect the seal area and inside the barrel of your Diaper Champ™ Deluxe.

Read all instructions BEFORE assembly and USE of product. KEEP INSTRUCTIONS FOR FUTURE USE.



IF YOU EXPERIENCE ANY DIFFICULTY IN USING THIS PRODUCT,
PLEASE CONTACT OUR CUSTOMER SERVICE DEPARTMENT AT
1-800-328-7363 BETWEEN THE HOURS OF 8:00 A.M. AND 4:30 P.M. PACIFIC
STANDARD TIME FOR ASSISTANCE. PLEASE HAVE YOUR MODEL NUMBER AND
MANUFACTURING DATE AVAILABLE WHEN YOU CALL.



Contact us by mail: Baby Trend, Inc. 1607 S. Campus Ave., Ontario, CA 91761 Contact us by phone: 1-800-328-7363 (8:00am ~ 4:30pm PST) or online http://www.babytrend.com



**Instruction Manual** 



02.09

www.babytrend.com