

# MOTOROLA IMPRES CHARGER LIGHT INDICATOR SHEET

## STEADY LIGHT

**RED**

**Rapid Charge:** Battery is in rapid charge mode

**ORANGE**

**Reconditioning Mode:** Your battery is in reconditioning mode. However long your battery remains in this mode depends on the remaining charge of your battery. Fully charged batteries require more time than fully discharged batteries.

**GREEN**

**Fully charged:** Your battery has completed its charge

## FLASHING LIGHT

**RED**

The battery is unchargeable or not making proper contact.

**ORANGE**

The charger has recognized your battery but is waiting to charge. Voltage or Temperature could be too high/low. When corrected, the battery will start charging.

**GREEN**

The battery has completed a rapid charge. The battery is now in top-off charge

**RED & GREEN**

Battery is fully charged. Battery continues to be usable but may be nearing end of service life.

## HOW TO START RECONDITIONING MODE

### MANUALLY

Insert your battery into the charger, and within the first 2.5 minutes, remove and insert the battery within 5 seconds. This will manually start the reconditioning process. The charger should change from steady RED to steady ORANGE

### AUTOMATICALLY

There is no need to do anything. IMPRES chargers are designed to know when its time to start the reconditioning process. When it needs to be reconditioned, the charger will show a steady ORANGE. When it's done reconditioning your battery, the charger will start recharging the battery.

### STOP RECONDITIONING

To stop the reconditioning process, remove and reinsert the battery within 5 seconds. This will end the recondition process and start charging. It should now show a STEADY RED.



For More Information Scan Here:

