


INSTALLATION & MAINTENANCE GUIDE



ltem #	Product Description	
370209	Stand Light Fixture Hanger (Single	
70210	Stand Light Fixture Hanger (2 PK)	

LIGHT FIXTURE HANGER INSTALLATION

PARTS LIST





BASE ATTACHMENT

Upright with Mounting Base: Locate a wood support on the back of the aquarium stand that is suitable to handle the weight of the fixture. Determine the location and secure the base to the wood with the supplied six screws.



TIP: Position the base so that the top of the Upright is at least even with or higher than the top of the aquarium when mounted. This will allow access to the Hand Tightening Knob located on the Upright when mounting two Light Fixture Hangers on the same aquarium, it is best to level the two prior to securing all twelve screws. A level that can span both hangers is useful to help keep them at the same height.






LIGHT FIXTURE HANGER INSTALLATION

ADJUSTABLE MOUNTING PLATE ©

After the Upright $oldsymbol{\Phi}$ is mounted, place the Adjustable Mounting Plate over the square tube and position the plate as high on the aquarium stand as possible. Secure the four screws to the aquarium stand through the mounting plate. Turn the Hand Tightening Knob so that the Upright $oldsymbol{\Phi}$ is secure and movement of the Upright is minimal.




TIP: The wider the distance between the Upright Mounting Base **A** and the Adjustable Mounting Plate **G**, the more stable the Upright will be on the aquarium stand.



ADJUSTABLE UPRIGHT ATTACHMENT 13

Adjustable Upright: After installing and securing the base of the Light Fixture Hanger , attach the Hand Tightening Knob to the top of the base where the female threaded nut/ connection is located. Turn the knob into the base a few turns, but not the entire way. The Adjustable Upright needs to slide into the base before securing.

Insert the Adjustable Upright f B into the Upright with Mounting Base f A, into the square tube and position approximately 12 inches above the top of the aquarium frame, tighten the Hand Knob f D to secure the Upright. Position the second Upright if used in the same manner.





WARNING: Tighten knobs securely so that the Upright does not move. Your light fixture will be attached and should not be allowed to contact the water.

FIXTURE MOUNTING

The Universal Light Fixture hanger includes a STOP at the end of the Upright to prevent a mounting wire from sliding off the hanger. Most fixture suspension options use a wire loop design and can be looped over the end of the Upright. After the light fixture is in its final position, use the supplied zip ties to secure the fixture power cord onto the Upright to prevent the cord from sliding.



TIP: Review the installation instructions for your fixture prior to installing the Light Fixture Hanger.



Bringing the Ocean to You, Wherever You May Be and Life Rewards are trademarks of Aquatic Life LLC Commerce, CA 90040 www.aquaticlife.com

© Copyright Aquatic Life LLC

P/N 9000061 REV 05/11

Copyright © Aquatic Life, LLC All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means without the prior written consent of Aquatic Life, LLC.

Aquatic Life, LLC

Commerce, CA 90040
Toll-Free US only: (888) 548-3480
Outside the US: 1-818-768-6943
customersupport@aquaticlife.com

Check us out on...







