

REMOVING MATS

Jorgensen Albums use an aggressive double sided tape that isn't meant to be easily removed. But from time to time, you may need to remove a mat that has already been inserted in the album. Whilst we can't guarantee that you'll not damage the page base, mat or images, if you follow these steps, you should at least minimize it.

1. Always remember to pull the mat towards the centre, starting in each corner.
2. Dip the blade of either a scalpel or thin bladed knife into a Lacquer Thinners or nail polish remover. This helps to dissolve the tape.



3. Lifting the front edge of the mat, insert the blade dipped in thinners and using a sawing action begin to peel the mat back towards the centre.



4. Repeat in each corner.