∧ Attention

Cautions:


- Read the manual: Before using this product, make sure to read the manual.
 This will help you understand how to use it correctly and prevent any accidents or damage to your devices.
- Do not expose to extreme temperatures: Avoid exposing this product to extreme temperatures, such as direct sunlight or below freezing conditions, as this can damage the internal battery and reduce its lifespan.
- Keep away from water: Avoid exposing this product to water or other liquids, as this can cause a short circuit and damage the device.
- 4. Don't overcharge or discharge: Avoid overcharging or completely discharging this product, as this can damage the internal battery and reduce its lifespan.
- 5. Do not expose the product to temperatures over 40°C including direct sunlight, a car on a hot day or ovens. This may cause over-heating, fire or explosion.
- Charge this product in a well-ventilated area and avoid charging under pillows, blankets, or on flammable surfaces to prevent overheating or fire.
- 7. Do not use in a strong electrostatic or electromagnetic environment, including near microwaves, as this may shorten the device's life.
- 8. Do not damage or puncture the casing of this product. This may cause over-heating, fire, or an explosion.
- 9. Do not clean with a wet cloth or other cleanser.
- Never leave a charging battery unattended.
- 11. If the product emits an odour, excessive heat, or becomes discoloured or distorted, discontinue use immediately.
- 12. Refer all servicing to qualified service personnel, which is required if the product is damaged in any way, is exposed to liquid, or does not operate normally. Please do not attempt to service or open the device. This may cause over-heating, fire, or an explosion.
- 13. Children must be supervised when using or handling this product.

Recommendations:

- 1. Operating temperature: 0°C~35°C.
- Storage temperature: -5°C~35°C with humidity ranging from 45% to 80%.
 Use good quality chargers and cables to recharge this product to reduce the
- chance of over-charging or over-heating.

 4. If not used for three months or more, the battery capacity may be reduced. If
- this happens, cycle the battery through 3-4 charge and discharge.

 5. To maintain the battery life, keep 50% or more capacity and charge this
- To maintain the battery life, keep 50% or more capacity and charge this product at least every 3 months.
- At the end of the power bank's life, please dispose of this product at a battery recycling station. It is not suitable for domestic waste disposal.




walkntalk

Quick Start Guide

What's included:




Product Overview:



1. Charging your devices

Connect the power bank's built-in charging cable (lightning or USB-C) to your chosen device, if the power bank is off, tap the Torch on/off button to start charging.

When charging, the power bank's battery status indicator will light up indicating it's charging your device.




When the Torch on/off button is pressed and released the 4 LED lights indicate the remaining power bank charge i.e., 4 lights indicate a full power bank, 1 light indicates less than 25%.

When the Torch on/off button is pressed and held down for 3 seconds the Torch light will turn on. Tap again and the Torch light will flash intermittently, tap once more to turn the Torch light off.

2. Recharging your power bank

- To recharge your power bank, connect it to a compatible USB power source using the provided USB-C cable, and then plug the USB-C end into the charging port on the power bank.
- The battery status indicator will flash to indicate the power bank is recharging.
- The power bank is fully charged when the 4 LED lights are on and have stopped flashing.



3. Specifications

Battery Capacity: 7.4Wh. 2000mAh

USB-C Input: 5V/2A 10W Max

Lightning Output: 5V/2A 10W Max

USB-C Output: 5V/2A 10W Max

Shared Output: 5V/2A 10W Max

4. For more information

For the most up-to-date assistance, please scan this QR Code for more information about this product.



Stay Connected







walkntalk