

Francfranc

CESTBEAU SIDE / COFFEE TABLE ROUND

セボ サイド / コーヒー テーブル ラウンド

取扱説明書

この度は、本製品をお買上げ頂きまして、誠にありがとうございました。

この商品を末永く安全にご使用いただくために、この取扱説明書をよく読み内容をご理解いただいた上で、別紙組立説明書と合わせ正しく商品を組立てて、ご使用下さい。

また、この取扱説明書、及び組立説明書は必要に応じて、いつでもご確認できるよう保管して下さい。

■設置について

- 商品は平らな場所に水平に設置して下さい。傾斜、段差のある場所など、不安定な場所でのご使用は、転倒、破損、ガタツキの原因となります。
- 直射日光のあたる場所、エアコン・ストーブなどの冷暖房器の近くや、高温多湿の場所、極端に乾燥した場所での使用はしないで下さい。
火災、変色、変形、破損の原因になります。
- フローリングや畳などの表面の傷防止の為に、商品と床の設置場所にカーペットなどを敷く事をお勧めします。
- 新品のうちは塗装臭、接着臭が残っている場合があります。室内で使用する場合はしばらくは換気をし、風通しの良い場所で放置して下さい。

■ご使用上の注意

- この商品は家庭用として企画されたものです。業務用としてのご使用はできません。
- 本品、天板の耐荷重は3kgです。この耐荷重は、天板一面全体に荷重がかかった場合の表示です。
- テーブル以外のご使用はお避け下さい。また遊具的なご使用や踏み台代わりに商品の上に立ち上がらないで下さい。転倒・ケガ・破損などの原因となります。
- 背の高いものを載せた場合、転倒し、破損のおそれがあります。天板にものを載せる場合は転倒の恐れが無いことをご確認の上ご使用下さい。
- 移動する際、押したり引いたりする事で床に傷がついたり破損などのおそれがあります、必ず持ち上げて移動して下さい。
- やかんや鍋など加熱した物を直接商品に置かないで下さい。火災、変色、変形、破損の原因になります。
- 底のザラついたものを直接のせるとキズの原因になります。
- 濡れた食器などを直接商品に置かないで下さい。変色、輪じみなどの原因になります。コースターやランチョンマットをお使い下さい。
- 商品の一部に手をついたり、過度の荷重を加えないで下さい。転倒、変形、破損などの原因になります。
- 天板の端に手をついたり、重いものを端に寄せて載せたりしないで下さい。転倒による思わぬケガ、器物破損の原因になります。
- 天板にものをのせる場合、面に満遍なくのせて下さい。たわみや割れの原因になります。
- 天板より大きいものを載せると、落下、破損などの原因になります。必ず天板の内側に入るようにして下さい。
- この商品は強化ガラスですが、一点に集中荷重が掛かるご使用は破損の危険がありますのでご注意下さい。
- 別紙、強化ガラスの商品特性をよくお読みの上、ご使用下さい。

■保守・点検

- お客様による商品の改造、修理は行なわないでください。強度が弱くなり、破損、ケガなどの原因になります。
- 製品に使用される塗料や接着剤にはホルムアルデヒドが含まれることがありますので、室内で使用する場合は普段からこまめに換気をして下さい。
換気の際は、2カ所以上の窓を広く開けたり、換気扇や扇風機を併用することをお勧めします。

■お手入れ方法

- 普段のお手入れは柔らかく良く絞った布で軽く拭いて下さい。硬い布地を使用されますと商品に細かな傷がつくことがあります。
- 化学雑きん、アルコール、ベンジン、シンナー、除光液などを使用したお手入れは避けて下さい。変色、しみ、塗装剥離などの原因となります。

Thank you for purchasing a Francfranc product.

Please read this instruction before assembly for preservation and safe use, and keep this instruction as well as assembly instructions for future reference.

■ Environment

- Avoid placing the furniture near cooling/heating equipment or in any place subjected to direct sunlight or high temperature/humidity to prevent fire, discoloration, deformation or damage.
- Place the furniture on a flat floor and avoid unstable place to prevent falling, damage or rattle.
- It is recommended to lay a carpet under the furniture to prevent scratches on the floor.
- It is recommended to open the window or doors soon after purchasing to get a fresh air because there is an odor left from the furniture materials as well as sub-materials.

■ Caution

- This furniture is intended for household use only.
- Load capacity of the glass top is 3 kg. This load capacity is in case of loading the entire surface of glass top evenly.
- Do not play with or stand on the furniture. It may cause falling, injury or damage.
- Avoid putting tall objects on the furniture to prevent them from falling and subsequent damage.
Make sure the object is stable before putting it on the furniture.
- Do not drag or push the furniture when move it. Always lift it when move it.
- Do not put heated object directly on the furniture. It may cause fire, discoloration, deformation or damage.
- Do not put object which has rough surface on its bottom directly on the furniture. It may cause scratches and scars.
- Do not put wet object directly on the furniture. It may cause discoloration or spot. Use coaster and place mat to avoid them.
- Do not apply too much pressure on a particular part of the furniture. It may cause warp, falling, deformation or damage.
- Do not put your hands and any heavy object on the edge of table. It may cause unexpected injury or damage.
- Avoid putting bigger objects than table top on the furniture to prevent them from falling and subsequent damage.
Make sure the object is not bigger than tabletop.
- Please read the another tempered glass instruction carefully.

■ Maintenance

- Do not remodel/repair the furniture by yourself. The strength of the furniture will decrease and cause damage or injury.
- Please be noted that paintings and adhesives used for this product contain a certain amount of formaldehyde.
It is recommended to ventilate your room frequently if it is used indoors.
It is ideal to leave two or more windows wide open or use ventilation fan or electric fan at the same time.

■ Cleaning Care Instructions


- Wipe clean with a soft well-wrung cloth regularly. Avoid abrasive cloth to prevent scratches.
- Avoid using chemically treated cloth, alcohol, benzine, thinner and polish remover to prevent discoloration, stain or peel-off of coating.

ガラスの商品特性について

この度は、Francfranc の家具をお買い上げ頂きまして、誠にありがとうございました。
ご使用になる前に、下記をお読みいただき、製品の特徴をご理解いただいた上でご使用いただきますようお願い致します。

■強化ガラスについて

本商品は強化ガラスを使用しています。強化ガラスは通常の板ガラスを700℃近くまで加熱した後
空気を均一に吹き付けて冷却し、急冷することによりガラス表面に圧縮層を持たせたガラスです。
通常の板ガラスに比べて3～5倍の強度があり、また万一割れても細粒状になり安全性の高いガラスです。



しかし、表面の傷つき易さは板ガラスと同様になります。

表面の傷が内部まで進行した時、ガラス全体にかかる力のバランスが崩れ、急に大きな音をたてて細かく砕け散る
特性があります。

また、強化ガラスは耐熱ガラスではありませんので急激な温度変化(急熱急冷)で割れることがあります。

目に見えない無数の傷が割れを生じさせることもあります。



通常のガラス



強化ガラス

■ご使用上の注意

- 温度が急激に変化する場所、又は、用途でのご使用は避けてください。特にテーブルコンロやホットプレート、IHクッキングヒーターなどご使用にならないようお願い致します。
- 長時間のパソコンの使用も機種によってはガラス面に熱をかけることとなりますので、お避け下さい。
- ガラス天板のエッジ部に衝撃を加えないで下さい。破損の原因となります。
- ガラス面の傷が原因で強化ガラスが破損する場合があります。お取扱いには十分ご注意下さい。
- ガラス天板を持ち上げる際、一箇所に負担がかからないようお取扱い下さい。ガラス天板の破損につながります

Francfranc


TEMPERED GLASS

Thank you for purchasing Francfranc product.

Please read this instruction carefully before using for long-term safe use, and keep them for future reference.

■Property

The tempered glass is made by heating the regular glass to around 720°C. The glass is then rapidly cooled down with forced air drafts to create balanced internal stresses on its surface. The tempered glass is 3~5 times stronger than regular glass. Also, tempered glass is a type of safety glass that crumbles into small granular chunks when breakage.



However, the surface of the tempered glass is easy to get scratched that is the same as the regular glass. If the scratch on the surface of the tempered glass is kept heat and rapidly cooled down repeatedly, the balance of the whole piece of glass will be broken and crumbling into small granular chunks will occur. Besides, tempered glass is not heat-resistant. The rapid temperature change on the scratch will cause breakage easily. Even invisible scratches may cause the breakage.



Regular glass



Tempaered glass

■Caution

- Please do not use the product in an area with drastical temperature changes. Please do not use portable cooker or hotplate etc.
- Do not work on the tempered glass for long time by personal computer in order to avoid giving heat.
- Do not hit the edge of glass sheet. Breakage may be caused.
- Do not scratch the surface with sharp objects as the scratch may cause damage.
- Do not apply too much pressure on an area on the glass or damage may be caused.