

この度は、本製品をお買上げ頂きまして、誠にありがとうございました。

ご購入いただきました商品を末永く安全にご使用いただくために、この取扱説明書をよくお読みいただき

内容をご理解いただいた上で、別紙組立説明書と合わせ正しく商品を組立てて、ご使用下さい。

また、この取扱説明書と別紙組立説明書は必要に応じて、いつでもご確認できるよう保管して下さい。

### ■設置について

- 商品は平らな場所に水平に設置して下さい。傾斜、段差のある場所など、不安定な場所でのご使用は、転倒、破損、ガタツキの原因となります。
- 商品は壁から離して設置してください。壁面に商品の色が移行する現象が発生する場合があります。
- 室内で使用する場合、エアコン・ストーブなどの冷暖房器の近くや、高温多湿の場所での設置、使用はしないで下さい。火災、変色、変形、破損の原因になります。
- フローリングや畳などの表面の傷防止の為に、商品と床の設置場所にカーペットなどを敷く事をお勧めします。
- 新品のうちは塗装臭、接着臭が残っている場合があります。しばらくは換気をし、風通しの良い場所で放置して下さい。

### ■ご使用上の注意

- この商品は家庭用として企画されたものです。業務用としてのご使用はできません。
- 座る以外の目的では使用しないで下さい。また、肘掛けや背もたれの上に、腰掛けたり乗ったりしないで下さい。
- ご使用の際、片寄った位置でご使用になるとウレタンや布地等の消耗が均等でなくなります。末永くお使いいただく為にもバランスよくご使用下さい。
- 移動する際、押ししたり引いたりする事で本体や脚部が破損する恐れがあります。必ず2人以上で持ち上げ移動して下さい。
- 遊具的なご使用や踏み台代わりに商品の上に立ち上がらないで下さい。転倒、ケガ、破損などの原因になります。
- 極端に湿度の高い場所や濡れた状態でご使用いただくと衣服への色移りやカビ、におい等の発生原因になります。風通しのよい場所でご使用下さい。
- 濃色の為、摩擦により色落ち、色移りします。白や淡色製品と組み合わせでの使用はお避け下さい。
- 直射日光や照明に長時間照らされると変色する場合があります。
- 商品の一部に過度の荷重を加えないで下さい。転倒、変形、破損などの原因になります。
- 起毛タイプの布地は繊維の方向により色の濃淡が出ます。ブラッシングする事で色の濃淡が緩和できます。(ブラッシングは豚毛をお勧めします。)
- 起毛タイプの生地の商品特性として、見る角度で光の反射が異なり、色味が異なって見える場合がありますが不良ではありません。

### ■保守・点検

- 金具類はゆるみやぐらつきがないか定期的に点検し、ゆるみ始めたらしっかりと締め直して下さい。
- お客様による商品の改造、修理は行なわないでください。強度が弱くなり、破損、ケガなどの原因になります。
- 製品に使用される塗料や接着剤にはホルムアルデヒドが含まれることがありますので、室内で使用する場合は普段からこまめに換気をして下さい。換気の際は、2カ所以上の窓を広く開けたり、換気扇や扇風機を併用することをお勧めします。

### ■お手入れ方法

- カバーは洗濯方法(縫込みラベル)にしたがって、クリーニング店でドライクリーニングをおこなって下さい。
- 使用やドライクリーニングにより風合いが変化したり、毛羽立ち、毛羽抜け、毛玉が発生することがあります。特に湿潤による摩擦にご注意下さい。
- 本体の普段のお手入れは、硬く絞った布等で軽く拭き取って下さい。硬い布地を使用されますと商品に細かな傷がつくことがあります。汚れのひどい場合は、市販されている汚れ落としなどをお使い下さい。その際必ず汚れ落としの説明文をよく読みご使用下さい。汚れ落としの種類、使用方法によっては、シミ等が発生し症状を悪くする恐れがあります。
- 本体は化学雑きん、アルコール、ベンジン、シンナー、除光液などを使用したお手入れは避けて下さい。変色、しみ、塗装剥離などの原因となります。
- 粘着テープを使用したお手入れは、お勧め出来ません。毛羽の抜け落ちや汚れ付着の原因となります。

### Thank you for purchasing a Francfranc product.

Please read this instruction before assembly for preservation and safe use, and keep this instruction as well as assembly instructions for future reference.

#### ■ Environment

---

- Avoid placing the furniture near cooling/heating equipment or in any place subjected to direct sunlight or high temperatures/humidity to prevent fire, discoloration, deformation or damage.
- Place the furniture on a flat floor and avoid unstable place to prevent falling, damage or rattle.
- It is recommended to lay a carpet under the furniture to prevent scratches on the floor.
- It is recommended to open the window or doors while you are assembling furniture to get a fresh air because there is an odor left from the furniture materials as well as sub-materials.

#### ■ Caution

---

- This furniture is intended for household use only.
- Please be noted that it may cause wearing breakage if it is used incorrectly.
- Please be noted that it may cause wearing deforming or breakage on seat if it is used incorrectly.
- Do not drag or push the item when move it. Always lift it with 2 or more people.
- Do not play with or stand on the furniture. It may cause falling, injury or damage.
- Please be reminded that it may cause mold or odor from mold while it is placed in the air with extraordinary humidity.
- Please be reminded that the dark color may cause the color running from the fabric by rubbing.
- Avoid placing the furniture in any place subjected to direct sunlight, which may cause color change or fading.
- Raised fabric looks dark or light depend on the direction of fabric. Brushing is recommended to adjust the shade of fabric.
- Do not apply too much pressure on a part of sofa, such as backrest and armrest. It may cause falling, deformation or damage.

#### ■ Maintenance

---

- Do not remodel/repair the furniture by yourself. The strength of the furniture will decrease and cause damage or injury.
- Periodically check to ensure that all components are properly tightened. Re-tighten them when necessary.
- Please be noted that paintings and adhesives used for this product contain a certain amount of formaldehyde.  
It is recommended to ventilate your room frequently if it is used indoors.  
It is ideal to leave two or more windows wide open or use ventilation fan or electric fan at the same time.

#### ■ Cleaning Care Instructions

---

- Follow the instructions on the tag attached inside of the fabric cover and wash it at a professional dry-cleaning store.
- Appearance changing, fluffing, nap falling-off, or piling may be occurred from usage or dry-cleaning.  
Please especially be careful with rubbing in wet condition.
- Wipe clean with a soft well-wrung cloth regularly. Avoid abrasive cloth to prevent scratches.
- Use a commercially available dirt cleaner if the dirt is serious. Read the instruction manuals carefully before applying.
- Avoid using chemically treated cloth, alcohol, benzine, thinner and polish remover to prevent discoloration, stain or peel-off of coating.
- Avoid using sticky tape for maintenance. It may cause fabrics to fall out or get dirty.