

この度は、本製品をお買上げ頂きまして、誠にありがとうございました。

この商品を末永く安全にご使用いただくために、この取扱説明書をよく読み内容をご理解いただいた上で、別紙組立説明書と合わせ正しく商品を組立てて、ご使用下さい。

また、この取扱説明書、及び組立説明書は必要に応じて、いつでもご確認できるよう保管して下さい。

### ■設置について

- 直射日光のあたる場所、エアコンや、ストーブなどの冷暖房器具の近くや高温多湿の場所、極端に乾燥した場所でのご使用は、しないで下さい。火災、変色、変形、破損の原因になります。
- 商品は平らな場所に水平に設置してください。傾斜、段差のある場所など不安定な場所でのご使用は、転倒、破損、ガタツキの原因となります。
- フローリングや畳などの表面のキズ防止の為に、商品と床の設置場所にカーペットなどを敷くことをお勧めします。

### ■耐荷重について

- 本品、天板の耐荷重は ダイニングテーブル:25kg / コーヒーテーブル\_サイドテーブル:20kg です。
- この耐荷重は、天板、一面全体に荷重がかかった場合の表示です。

### ■ご使用上の注意

- この商品は家庭用商品として企画されたものです。業務用としてのご使用は出来ません。
- 背の高いものを載せた場合、転倒し、破損のおそれがあります。天板にものを載せる場合は転倒の恐れが無いことをご確認の上ご使用下さい。
- 天板より大きいものを載せると、落下、破損などの原因になります。必ず天板の内側に入るようにして下さい。
- 移動する際、押したり引いたりする事で床に傷がついたり破損などのおそれがあります、必ず2人以上で持ち上げて移動して下さい。
- やかんや鍋など加熱した物を直接商品に置かないで下さい。火災、変色、変形、破損の原因になります。
- 商品の一部に過度の荷重を加えないで下さい。転倒、変形、破損などの原因になります。
- 天板に物をのせる場合、面に満遍なくのせて下さい。たわみや割れの原因になります。
- 天板の周縁に手を付く、踏み台の代わりに使用する、お子様が天板上に立ち上がるなどした場合、転倒し、ケガの原因になります。
- 底のザラついたものを直接のせるとキズの原因になります。

### ■保守・点検

- 脚部のネジや金具類はゆるみやぐらつきがないか定期的に点検し、ゆるみ始めたらしっかりと締め直して下さい。
- お客様による商品の改造、修理は行わないで下さい。強度が弱くなり破損、ケガなどの原因になります。

### ■お手入れ方法

- 普段のお手入れは柔らかく乾いた布で軽く拭いてください。硬い布地を使用されますと商品に細かな傷がつくことがあります。
- 化学雑きん、アルコール、ベンジン、シンナー、除光液などを使用したお手入れは避けて下さい。変色、しみ、塗装剥離などの原因となります。

### Thank you for purchasing a Francfranc product.

Please read this instruction before assembly for preservation and safe use, and keep this instruction as well as assembly instructions for future reference.

#### ■ Environment

---

- Avoid placing the furniture near cooling/heating equipment or in any place subjected to direct sunlight or high temperature/humidity to prevent fire, discoloration, deformation or damage.
- Place the furniture on a flat floor and avoid unstable place to prevent falling, damage or rattle.
- It is recommended to lay a carpet under the furniture to prevent scratches on the floor.
- It is recommended to open the window or doors soon after purchasing to get a fresh air because there is an odor left from the furniture materials as well as sub-materials.

#### ■ Load Capacity

---

- Load capacity of the top-board is DT : 25kg / CT\_ST:20kg

#### ■ Caution

---

- This furniture is intended for household use only.
- Avoid putting tall objects on the furniture to prevent them from falling and subsequent damage. Make sure the object is stable before putting it on the furniture.
- Avoid putting tall objects on the furniture to prevent them from falling and subsequent damage. Make sure the object is stable before putting it on the furniture.
- Do not drag or push the furniture when move it. Always lift it with 2 or more people.
- Do not put heated object directly on the furniture. It may cause deformation or damage and get burned.
- Do not apply too much pressure on a particular part of the furniture. It may cause warp, falling, deformation or damage.
- Do not put object which has rough surface on its bottom directly on the furniture. It may cause scratches and scars.
- Do not apply too much pressure on a particular part of the furniture. It may cause warp, falling, deformation or damage.
- Please be reminded that it causes as a material property if any chance damaged, the debris may turn into strip or sharp shards and scatter vigorously.

#### ■ Maintenance

---

- Periodically check to ensure that all components are properly tightened. Re-tighten them when necessary.
- Do not remodel/repair the furniture by yourself, the furniture will be decreased its strength, and cause damage or injury.

#### ■ Cleaning Care Instructions

---

- Wipe clean with a soft well-wrung cloth regularly. Avoid abrasive cloth to prevent scratches.
- Avoid using chemically treated cloth, alcohol, benzine, thinner and polish remover to prevent discoloration, stain or peel-off of coating.