

## *fuse* – 12 MONTH WARRANTY

Fuse will replace the faulty product at no cost to the consumer. The warranty does not extend to any consequential damages or cost that may be incurred and is valid for 12 months from date of purchase. The consumer must return the faulty product to the retail store it was purchased from together with proof of purchase.

The warranty is provided by:  
Pacific Optics (in Australia)  
18 Taree St, Burleigh Heads, QLD 4220  
Telephone: (07) 5593 4222  
Email: info@fuseaudio.com.au

Signature Marketing NZ Ltd (in New Zealand)  
25a Triton Drive, Rosedale, Auckland 0632  
Telephone (NZ): (09) 479 5524  
Email (NZ): sales@signaturenz.com

The benefits to the consumer under this warranty are in addition to other rights and remedies of the consumer under Australian laws in relation to the goods to which the warranty relates. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

# *fuse*

## DRIPPIN BEAT PORTABLE BLUETOOTH SPEAKER




AFS-BT-WP-BLK

## *fuse*


### QUICK START GUIDE

#### WHAT'S INCLUDED:




#### 1. CHARGE YOUR SPEAKER

Fully charge before using the first time using the supplied cable. A red light behind the speaker grille will switch on to indicate the speaker is charging and switch OFF when fully charged.




## 2. CONNECT YOUR SPEAKER



When the speaker is fully charged, press the power **O** button for **2 seconds**.



Turn **Bluetooth** ON in your phone settings and select **Fuse Drrippin Beat** from the available Bluetooth devices.



## 3. USE YOUR SPEAKER



**Turn Speaker ON/OFF** Press **O** for 2 seconds

**Change audio source** Press **O**  
*Bluetooth, FM, TF Card and AUX*

**Play/Pause** Press **▶||**

**Answer/Hang up call** Press **▶||**

**Reject incoming call** Press **▶||** for 2 seconds

**Redial call** Press **▶||** for 2 seconds

**Previous track** Press **◀◀**

**Next Track** Press **▶▶**

**Volume down** Press **◀◀** for 2 seconds

**Volume up** Press **▶▶** for 2 seconds

## 4. DOWNLOAD USER MANUAL

For the most up-to-date assistance, please **scan this QR Code** to download the full User Manual before using this product.



***fuse***