

INSTRUCTION BOOKLET

PLEASE KEEP FOR FUTURE REFERENCE

SAFETY INFORMATION



WARNING!

DEATH or serious **INJURY** can occur Read all instructions before use

- Baby Change-N-Go is designed for infants/toddlers **ONLY**. Age up to $2\sqrt{2}$ years and weighing less than 40 lbs.
- Baby Change-N-Go has been specifically designed for public bathroom stall doors/stall walls no higher than 75" tall. It has **NOT** been designed for full size doors, car doors, port-a-potties, airplane bathroom doors or any other applications.
- FALL HAZARD! DO NOT leave your infant/toddler unattended while in Baby Change-N-Go. ALWAYS have one hand on your child while your child is in Baby Change-N-Go.
- **ALWAYS** use restraint system while infant/toddler is in Baby Change-N-Go to avoid serious injury or death from falling or sliding out.
- Baby Change-N-Go IS NOT a bed. NEVER allow your infant/toddler to sleep in Baby Change-N-Go.
- Snugly adjust the safety strap provided with this changing station around your infant/toddler. A snug safety strap should not allow any slack. It does not press into the infant's/toddler's flesh or push their body into an unnatural position.
- Follow all instructions on this baby changing station and in the written instructions provided.
- Register your Baby Change-N-Go with the manufacturer.
- Store Baby Change-N-Go in a safe place when it is not being used. Avoid placing heavy objects on top of it.
- **DO NOT** leave infant/toddler alone in changing station, even for a short time.
- DO NOT attempt to disassemble any part of the changing station or change the way the changing station is used
- **DO NOT** allow infant/toddler/child to play with this changing station.

INSTRUCTIONS FOR USE

WARNING!

Read all instructions before use.

Failure to follow instructions for use can result in serious **INJURY** or **DEATH**.

DO NOT USE IF DAMAGED OR BROKEN.

OPENING BABY CHANGE-N-GO FOR THE FIRST TIME

STEP 1



Your Baby Change-N-Go arrives folded. Lay it on a flat surface like pictured above.

STEP 2



Begin opening it by pulling hook section up and away from the base.

STEP 3









Continue unfolding as pictured above. (Product may arrive folded in a "z" pattern.)

INSTRUCTIONS FOR USE

CAUTION!

It is strongly advised that User of Baby Change-N-Go practice hanging product on bathroom stall door/stall wall, unfolding it and folding it up until comfortable with how it works **PRIOR** to placing infant/toddler on the changing station for the first time.

CAUTION!

When opening Baby Change-N-Go after hanging on bathroom stall door/stall wall, **OPEN SLOWLY** in order to avoid injury to yourself or your infant/toddler.

HANGING AND OPENING BABY CHANGE-N-GO

STEP 1



Hang hooks of Baby Change N-Go on stall door, Ensure both hooks are hung correctly.

STEP 2







SLOWLY unfold Baby Change-N-Go to fully open position.

STEP 3





Carefully lay infant or toddler in Baby Change-N-Go, making sure the infant/toddler is completely in the changing station, centered lengthwise and secure the safety strap over infant's/toddler's waistline (as seen in pictures.)

INSTRUCTIONS FOR USE

CAUTION!

When closing Baby Change-N-Go after use, **CLOSE SLOWLY** in order to avoid injury to yourself or your infant/toddler

CLOSING BABY CHANGE-N-GO

STEP 1





Grasping the front center of the changing station, press toward the stall wall/stall door and up to flatten the changing station.

STEP 2



Fold the two sides; one toward the back and one toward the front (Z pattern).

STEP 3



Slowly fold upward and under three times: **CAUTION!** Changing station can reopen on its own due to gravity—hold securely.

STEP 4



Firmly grasp
Baby ChangeN-Go and lift
up to remove
hooks from
stall door/
stall wall.

View an instructional video of how to fold Baby Change-N-Go at www.BabyChangeNGo.com.

CARE INSTRUCTIONS

- DO NOT ATTEMPT TO DISASSEMBLE Baby Change-N-Go to clean.
- Simply wipe surfaces of Baby Change-N-Go with a damp cloth with mild soap.
 Use a clean dry cloth or towel to wipe any excess liquid away
- **DO NOT** machine wash or dry.
- DO NOT use abrasives, solvents, strong detergents, or household cleaners.
 These products can scratch, discolor, and weaken materials or cause corrosion on metal surfaces.
- DO NOT fold Baby Change-N-Go up when damp or wet
- Store Baby Change-N-Go away from extreme heat

WARRANTY

This product is distributed by Baby Change-N-Go. Baby Change-N-Go warrants this product to the <u>original retail purchaser</u> as follows:

LIMITED WARRANTY

If any defect is discovered within 10 days of purchase, please return to your retailer for exchange or contact Baby Change-N-Go at 804-320-2369. You will be given an exchange authorization number and asked to send us the defective product, postage prepaid, along with proof of purchase. Please send the product to Baby Change-N-Go, 2711 Buford Road, Ste. 327, Bon Air Virginia 23235. Proof of purchase is required. Your exclusive remedy for this warranty is that Baby Change-N-Go will, at its option, provide repair or replacement components to the original purchaser for this product or replace the product. Baby Change-N-Go reserves the right to discontinue or change fabrics, parts, models or products, or to make substitutions. Labor and shipping costs for returns are not included.

To make a claim under this Warranty, you must contact Baby Change-N-Go Customer Services Department at 1-804-320-2369 or write to 2711 Buford Road, Ste 327, Bon Air Virginia 23235. Proof of purchase is required.

PLEASE COMPLETE AND MAIL THE REGISTRATION CARD WITHIN 30 DAYS OF PURCHASE, OR VISIT **WWW.BABYCHANGENGO.COM/REGISTRATION**.

WARRANTY LIMITATIONS

This warranty does not include damages, which arise from negligence, misuse, salt corrosion, or use not in accordance with the user guide.

The use of non-BABY CHANGE-N-GO accessories is not approved by Baby Change-N-Go. The use of unapproved accessories could cause this product to become damaged or dangerous. Their use may void the Baby Change-N-Go warranty.

The warranty and remedies as set forth above are exclusive and in lieu of all others, oral or written, express or implied. In no event will Baby Change-N-Go or the retailer selling this product be liable for any damages, including incidental or consequential damages, arising out of the use, misuse or inability to use this product.

REGISTRATION INFORMATION

REGISTRATION

Changing tables could be recalled for safety reasons. You must register this changing station to be reached in a recall. Send your name, address, email address if available and the changing station's model number and manufacturing date via the enclosed Product Registration card to Baby Change-N-Go, 2711 Buford Road, Suite 327, Bon Air Virginia 23235 or register online at www.BabyChangeNGo.com/registration. For recall information, call the Consumer Product Safety Commission at 800-638-2772, TTY 301-595-7054. For your convenience, record all the information about your changing station below. Refer to the serial number and manufactured date label inside the top pocket of the changing station for all of the necessary information.

Model Name: BCG01	
Color:	
Date of Manufacture:_	
Date of Purchase:	