

UBALL

INSTRUCTION MANUAL & RULES

BALL ANYWHERE

Table of Contents

How to Play UBALL	3
Filling Sand Pouches	4
Set Up	5
Base Assembly	6
Base Anchoring - Sand Use.....	9
Base Anchoring - Grass/Other Use	10
Rim Connection	11
Final Assembly	16
Pack Up	18
Disassembly	19
Backpack Form	21

How to Play UBALL

1. **No Dribbling** - You get **3 steps** before you have to pass or shoot
 2. **No Out of Bounds** - You can go behind the hoop like hockey or lacrosse
 3. **Baskets are 1 and 2 Points** (half courts shots are 2 pts)
-

Half-Court Gameplay (1 Hoop)

- **Player count: 2-on-2 or 3-on-3**
- Teams must take the ball back on every change of possession
- Set take-back marker 20ft from basket

Full-Court Gameplay (2 Hoops)

- **Player Count: 3 on 3**
- Game begins with Tip-Off

Filling Sand Pouches

For Non-Beach Use

**Fill Sand Pouches with 100-120 Pounds of Sand
(Each Pouch Holds 20-23 Pounds)**

* Sand Available at Local Department Stores



* Recommended as a 2 Person Job

* If only 1 Person, a Scooper is Recommended

Set Up

(Recommended as a 2 Person Job)

1. Base Assembly
2. Base Anchoring
3. Rim Connection
4. Final Assembly

Warning:

Do not Assemble Hoop until Base has been Anchored

Base Assembly

1 Unscrew Base from the Backboard



Unscrew Here



2 Move Arms Forward



Before



After


3 Place / Fasten Bottom Pole in Base



Indented side of the pole should be on top



4 Fasten Arms to Bottom Pole



Tighten Knob to Fasten





Base Assembly Complete

Next Step: Base Anchoring

Base Anchoring - Beach Use

1 Pack a Liberal Amount of Sand on Base



*Make sure to Fully Cover Front Side of Base

Base Anchoring - Grass/Other Use

- 1 Lay 7 Sand Pouches on Base



Base Anchoring Complete

Next Step: Hoop Assembly

Rim Connection

Parts Needed for this Step:

Rim Knobs



Rim Connection

- 1 Place Upper Pole on Backboard




2

Place Rim through Upper Pole




3 Fully tighten Rim Knobs



Turn Backboard on its side

Once initially tightened, turn hoop upright to fully tighten



3

Fully Tightened Rim (Rim Shouldn't Wiggle)



Rim should be flush with the pole

Final Assembly

1 Fasten Middle Pole to Upper Pole (Set to Desired Height)




Fasten with
Silver Lock Pin

2 Place Hoop on Base / Fasten with Lock Pin



3

Place Pads on Pole



Final Assembly Complete

Ready to Play

Pack Up

1. Disassembly
2. Backpack Form

Disassembly

- 1 Remove Hoop from Base, then Disconnect Upper and Middle Poles





-
- 2 Unscrew Rim Knobs and Detach Rim



3

Detach Arms / Remove Pole from Base



Disassembly Complete

Next Step: Backpack Form

Backpack Form

1 Move Arms Back (Optional)



2 Fasten Backboard to Base



Use 2 Knobs to Tighten Base to Backboard

3

Fasten Rim to Base

(Optional - Rim can also be Carried by Hand)



* Place Rim Under Arms, then Fasten with Rim Fasteners





**Place Poles in Travel Case &
Backpack Form Complete**

SAFETY FIRST:

Always inspect your Uball hoop before and after you use it. If you notice something that just doesn't seem right, don't use the hoop. Call us immediately to let us know what the problem is and how we can help.

FOLLOW ALL INSTRUCTIONS:

For your safety, do not assemble Uball without following the instructions carefully. Before you start, identify all parts and confirm that they are all there. You can compare the picture of the parts in these instructions to properly identify each one. Each time you assemble Uball, you must take care to assemble it properly. This is important to reducing the risk of injury during assembly and gameplay. Someone could be seriously injured if Uball is not assembled, installed and played properly. Key call-outs:

- Check ground screw regularly. Look for corrosion or other defects that might compromise the stability of the ground screw.
- Before installing the ground screw confirm that the area is free of underground structures, such as wires, water pipes, etc. Failure to perform this check could result in serious injury or property damage.
- This equipment is intended for recreational use and is not intended for excessive competitive play.
- Read and understand all warning labels affixed to the equipment and in this instruction manual.
- The useful life of your Uball equipment depends on a number of conditions, including excessive use, hard gameplay, ground conditions, and climate.
- If you need technical assistance, reach out to our Customer Service team.
- Adult supervision is advised when assembly Uball.

LIMITED 1 YEAR WARRANTY

Uball LLC warrants this product to be free from defects in workmanship and materials, under normal residential use and conditions, for a period of one (1) year from the original invoice date. Shipping and handling fees for all returns are to be paid for by the customer. Uball LLC agrees, at its option during the warranty period, to repair any defect in material or workmanship or to furnish a repaired or refurbished product of equal value in exchange without charge (except for a fee for shipping, handling, packing, return postage, and insurance which will be incurred by the customer). Such repair or replacement is subject to verification of the defect or malfunction and proof of purchase as confirmed by showing the model number on original dated sales receipt.

This warranty does not cover damages resulting from accident, misuse or lost merchandise, and is valid in the USA. Register your product at uballanywhere.com to ensure warranty coverage. See our website (uballanywhere.com) for further details, including warranty limitations and claims procedures.

WARNING

FAILURE TO FOLLOW THESE WARNINGS MAY RESULT IN SERIOUS INJURY AND/OR PROPERTY DAMAGE

Owner must ensure that all players know and follow these rules for safe operation of the system.

- Do not hang on rim
- During play, especially when making dunks, keep player's face away from the rim, net and backboard. Serious injury could occur if teeth/face come in contact with the rim, net or backboard.
- During play, do not wear jewelry, (rings, watches, necklaces, etc.). Objects may entangle in net.
- Check the system before each use for loose hardware, signs of corrosion and repair before each use. This should include checking the rim/backboard connections and their threading, as well as the ground screw.
- Do not allow children to set up the system. An adult should always handle the setup.
- Only install the system on a flat surface to ensure stability of the system during game play.
- Before installing the ground screw confirm that the area is free of underground structures, such as wires, water pipes, etc. Failure to perform this check could result in serious injury or property damage.
- Use the probe device to assess the firmness and quality of the ground before installing the ground screw.
- After installing the rim to the pole and backboard, be certain that the bolts have been fully tightened. Then, check the rim to ensure that it is firm.

www.uballanywhere.com