




LINDGREN-PITMAN

S-3000 Electric Reel

Wiring Instructions

*To Operate 12/0 Penn Senator Reels
from Relay Controlled Power Converters*



Hubbell 23CM11 Plug Connections

Replace the (4) prong HUB-2421 plug with a (3) prong HUB-23CM11 plug. Connect only the black and green wires from your (4) wire cord as illustrated above. The red and white wires are not used. Connect a "jumper" from the silver colored terminal to the green colored terminal.

The plug will activate the relay as soon as it is inserted into the female receptacle on the power converter. Control the reel as normal with the large toggle switch on the reel.