

INSTALLATION INSTRUCTIONS LFP Series

LED Flat Panel

PLEASE READ INSTRUCTION BEFORE COMMENCING INSTALLATION AND RETAIN FOR FUTURE REFERENCES. Electrical products can cause death or injury, or damage to property. If in any doubt about the installation or use of this product, consult a competent electrician.

Applies to

LFP22XXAMV & LFP24XXAMV Series


Table 1: Product Specifications


Model	Watt	Input Voltage	LED Drive Current	Viewing Angle	Ra	PF	Dimming
LFP22XXAMV	40	100-277VAC	1000mA	120°	>80	>0.9	0-10V
LFP24XXAMV	50		1050mA				

Where XX represents CCT (30=3000K, 35= 3500K, 40=4000K, 50=5000K)


Note: Above table shows typical configurations. Additional options are possible based on customer needs, including – Emergency panel lights. Emergency power can be 4-20W for 90 minutes.


Recessed Installation





Installation Guide









INSTALLATION INSTRUCTIONS

LFP Series





WARNING

- LED Panels are not suitable for using in wet locations
- Please keep the LED Panel away from any corrosive substance, and please use dry cloth when you clean it
- LED Panel can only be installed by a qualified electrician.
- Before installation or maintenance, please disconnect the power to prevent electric shock.

The Installation must be carried out by a qualified electrician.

Page **2** of **2** Rev: **5/16/2018**