



Installation Guide WL-DL4 / WL-DL6


Installation diagram




















Notice

 Please read the specification first, to make sure the service environment matches the condition in the specification before using.



- Please confirm the applicable power supply before using.
- Make sure the switch of product is off before connect to the power supply to prevent electric shock.
- Operation against rules may damage your property even harm to your personal safety.
- Dangerous high voltage, Non-professionals are not allowed to maintain the products.
- If the exterior flexible cable or wire is damaged, it must exchange by the supplier, its agent or other similar qualified personnels to avoid dangers.