



DARK KNIGHT


ORIGINAL BY NORWAY

Table of Contents

Table of Contents	1
Product Contents	2
Operating Guide	3
Charging	5
Cleaning & Storage	6
Troubleshooting	7
Safety and Warning	8
Specifications	10
Disposal	11
Warranty	11

Product Contents


Product



USB Charging Cable





Suction Cup Base




※AC Adapter is not included.






Operating Guide




Before Using



Operating Guide




- Press & Hold  Button for 2~3 seconds to turn ON.
- The Indicator Light will lights up when the power is turned on and the product will enter working mode.
- To turn OFF the product, Press & Hold  Button again for 2~3 seconds.
- Within 15s after the power is turned off, the product will automatically adjust the position of the TPE Sleeve Cup to facilitate removal for cleaning.
- The Indicator Light will turn off when the power is turned off.
- Press  Button to switch Rotating & Thrusting modes when the power is turned on.
- Press  Button to activate/stop the Strongest Frequency mode when the power is turned on.
- Press  Button to manually adjust the position of the TPE Sleeve Cup when the power is turned off.

-  ALWAYS use water-based lubricant.
-  Silicone -based / oil-based lubricants / other oils such as massage oil or baby oil may cause damage to the product material.
-  This product is not waterproof. Do not soak it in water or splash it with water. It may cause a malfunction, fire or electric shock.


Charging

- Connect the USB Charging Cable and the charging port on the bottom of the product.
- Plug the USB Charging Cable into available PC USB port or AC Adapter.
- If connected properly, the Indicator Light will blink every few seconds.
- Once fully charged, the Indicator Light will always bright.



- ⚠ Please make sure that the adapter or computer USB port matches the product before connecting.
- ⚠ Please charge it fully before using it for the first time, or after a long time without using it.
- ⚠ To maintain the quality of the battery, please fully charge it at least once every six months.
- ⚠ Do not use a charging cable other than the dedicated USB cable provided.
- ⚠ The supplied USB charging cable is not waterproof. Please take care not to get it wet or submerge it in water.
- ⚠ To avoid electrical shock or burns and other accidents, please make sure your hands are dry before charging the product.

Cleaning & Storage



- Turn the upper part counter-clockwise to remove it from the main body.
- Take out the cylindrical case then take out the TPE Sleeve Cup inside.
- Please clean the TPE Sleeve Cup with water or lukewarm water.
- Please dry it with soft fabric after cleaning.



- If lube or dirt adheres to the product, wipe it off with a soft fabric that has been dampened and wrung out.
- Please clean it with mild soap or neutral detergent.
- This product is not waterproof. Do not immerse or splash water on it.
- Do not wash it with hot water.
- Do not boil it.
- Do not clean it with Banana oil, benzene, alcohol and other solvents which may cause product deformation and discoloration.

⚠ It is strictly forbidden to immerse the product in water when charging to avoid accidents such as electric shock, short circuit and fire.

⚠ Please avoid storing this product in places exposed to sunlight or in high temperatures or high humidity. This may cause discoloration, breakdown, heating or even a fire.

Troubleshooting

? The product does not work properly / Rotating & Thrusting is weak

- Did you hold the power button for 2~3 seconds after pressing?
- Is it fully charged?
- Please release the power until the product would not turn on and then fully charge it. If it still doesn't work after several trying, the battery might be damaged.

? The product can not be charged. (The Indicator Light does not blink)

- Is the charging cable disconnected from the adapter or charging port?
- When a PC USB port is used, the product will not charge if your computer goes into standby mode. Please check that if your PC is in standby mode.
- Dust and stains may be on the charging port. Please wipe it with a dry fabric or cotton swab before trying to charge it again.
- Is the product already fully charged? When fully charged, the indicator light will become solid instead of blinking.

? The charging will not be completed. (The Indicator Light does not lights up)

- Dust and stains may be on the charging port. Please wipe it with a dry fabric or cotton swab before trying to charge it again.
- If the indicator light is still blinking after 240 minutes of charging, it might be caused by a charging fault due to poor contact.

Safety & Warning

- If you are using a medical device / undergoing other treatment / pregnant, please consult your doctor before using.
- Stop use and consult a doctor or pharmacist if you experience any discomfort while using.
- When you find that the product is working abnormally, please immediately stop using and turn off the power to avoid injuries and accidents.
- Please keep it out of the reach of kids to prevent them from swallowing product parts or accessories by mistake.
- Please use the supplied USB charging cable when charging and connect it correctly, or it may cause overheating or burning.
- To avoid electric shock and burns, please keep your hands dry when you (un)plug the charging cable.
- Please turn it off before charging, or it may cause malfunction, heating, and burning.
- Please turn it off and cut off the power before cleaning.
- When unplugging the included USB charging cable, please hold the connector part and do not stretch the cable, or it may accelerate the cable aging and cause electric shock, short circuit, and even a fire.
- Please unplug the included USB charging cable when there is no need to charge, otherwise it may cause a short circuit due to dust and moisture and lead to electric leakage and fire accident.
- Please clean the USB charging cable connector regularly to avoid short circuits and fire accidents due to dust adhesion.
- Please turn it off after use.

Safety & Warning

- Please do not strongly impact or step on it.
- Discontinue use if discomfort occurs.
- DO NOT use when extremely tired or drunk to avoid causing other discomforts.
- DO NOT charge, use, or store in extreme temperatures, or it may cause burning or rupture.
- DO NOT forcefully pull or remove the silicone on the surface of the product to avoid product damage.
- DO NOT over-bend or pull the included USB charging cable and do not wrap the charging cable around the product for storage as this may result in damage to the charging cable.
- DO NOT use the included USB charging cable when it is broken, as it may cause electric shock, short circuit, and fire.
- DO NOT share this product with multiple people to avoid transmitting sexually transmitted diseases.
- DO NOT continue to use more than 15 minutes on the same body part.

Specifications

Product Name	DARK KNIGHT
Size / Weight	270×86×86mm / Approx. 708g
Running Time	Approx. 90min (Full Power)
Charging Time	Approx. 240min
Input voltage	AC 100-240V 50/60Hz
Output voltage	DC 5V /1A
USB cable length	81cm
Materials	ABS / TPE / Lithium-ion battery
Power source	Rechargeable (Lithium-ion battery)
Country of Manufacture	PRC

Disposal

Regarding disposal of Waste Electrical and Electronic Equipment (WEEE). The symbol below of a crossed-out dustbin indicates that this item should be taken to an appropriate collection point for proper disposal. Please do not dispose with household waste.



Warranty

This product is covered by Product Warranty for 1 YEAR from Original Date of Purchase against defects due to fault of production or materials.

Product Warranty covers working parts of the Product and does NOT cover the following:

- The product warranty has not been activated.
- Abnormal usage methods, or usage methods deemed inappropriate or otherwise mentioned as invalidating Warranty in this User Manual.
- Damages made during delivery of product, moving of product or accidental damages.
- Damages caused by natural disasters or use at wrong voltage.
- Cosmetic damage due to fair use of Product.