



Backwashing Is Easy



Backwashing

is a simple procedure to wash away any loose sediment or debris in the filter and restore flow.





Begin

by detaching the DirtGUARD from the spigot and remove the Inline Filter. Open and remove lid.



3

Attach

the Backwash Adapter to the hose end and tighten.



Insert

Hose End (with adapter attached) into OUTLET side of the DirtGUARD. This will be in the same place where the inline filter was removed.



5

Tighten

loosely....it is okay if it leaks a little. It will be easier to remove when finished.



6

Turn

on water on full and flush the filter for a few minutes.





Note: Filter staining will not be removed.