

Instruction Manual

Model: MP0620/MP0620A

4.2Amp Dual USB Charger with Voltmeter

Specification:

ос+

12.85

- * Input: 12-24V DC
- * Output: 5V DC, 4.2Amp (2.1A + 2.1A)
- * SAE Quick Release Connector
- * LCD display of battery / alternator voltage
- * Dual USB Ports for multiple devices

NOTE:

- * Use fuse protected cable to connect the USB charger with the battery for safety.
- * DO NOT connect the USB charger with the battery without fuse protection.
- * Keep the cap closed after each use to protect the USB ports from dust or water damage.
- * If the voltage of the battery is under 12V, the battery voltage is low and it should be charged.
- * The LCD screen will display "LO" when the battery voltage is under 5V, or display "HI" when the battery voltage is above 30V.

Warranty:

Register your product online to get 12months warranty.

- www.motopowers.com/warranty.html

Support:

For any product support or service, please contact us at **customerservice@motopowers.com**. Our professional customer service team will respond to you soon.

MANUFACTURER: MOTOPOWER INC.

MOTOPOWER INC. 16192 Coastal Hwy, Lewes, DE 19958. USA

www.motopowers.com

EU IMPORTER:

TRANSRITE INDUSTRIES CO., LIMITED 12 AV Roland Corrao, 13700 Marignane FRANCE 60 852111939

Email:sales@transrite.com

F© (E ROHS 🙆

Printed in China

