


EG740

Eagle Chain Secure for Slide Gates



The EG740 Eagle Chain Secure is designed to quickly tighten the chain on a slide gate. Over time, a slide gate's operating chain will need to be tightened. The EG740 Eagle Chain Secure allows this operation to be performed quickly and easily by merely cranking the chain tightening wrench provided. A properly tightened chain will perform much better than a neglected chain that naturally "stretches out" over time. The stretched out chain can cause damage and performance problems to the slide gate system.

Choose the Eagle Chain Secure Position (Left or Right) ONLY ONE Eagle Chain Secure is needed per slide gate.



Eagle Chain Secure is typically installed on the **SAME END** of the gate as the gate operator when gate is in the **CLOSED** position.

Chain Tightness

After chain connection, turn chain tightening wrench to tighten chain.

IMPORTANT: The chain can **ONLY** be tightened when Eagle Chain Secure is **FARTHEST** away from the gate operator (in **OPEN** position). The chain should sag no more than one (1) inch per 10 feet of travel. Chain can be easily tightened over time as it naturally stretches out. **Do not over tighten the chain.**

Installation

The chain locking gear **MUST** be mounted facing **OUTWARD**. Chain tightening wrench will **ONLY** fit in the chain locking gear opening.

