

OVERHEAD GATE HARDWARE







Overhead Jamb Track Hardware List

	1R	Power Arm - Right	22	Spring Bracket Hardware
	1L	Power Arm - Left	22-5	Spring Bracket Hardware (5")
	2	Inner Thrust Bearing		Connecting Link (3" & 4"springs)
	3	Main Pivot Bushing	23-5	Connecting Link (5" spring)
	4R	Main Pivot Bracket - Right	24	Spring Connecting Link Bushing(x2)
	4L	Main Pivot Bracket - Left	24-5	Spring Connecting Bushing (5")
	5	Outer Thrust Bushing	25	Spring Connecting Link Bolt 3/8"
	6	Flat Washer 3/4"	25-5	Spring Connecting Link Bolt 1/2"
	7	Nylon Threaded Nut 3/4"		Spring Connecting Link Bolt 1/2"
	8	Label 2" X 11"	26-5	Spring Connecting Link Bolt 3/4"
	9	Lower Pivot Bushing (x2)	27	Connecting Link Nylon Nut 3/8"
	10	Lower Pivot Pin (Tapered)	27-5	Connecting Link Nylon Nut 5/8"
	11	Lower Pivot Pin Retaining Clip	28	Connecting Link Nylon Nut 5/16"
	12	Lower Pivot Bracket	28-5	Connecting Link Nylon Nut 3/8"
	13	Kicker Roller Bracket (3")	29	Spring End With Saddle (3"& 4")
	14	Kicker Roller Shaft	29-5	Spring End With Saddle (5")
	15	Kicker Roller	30A	Spring-3"
	15A	Kicker Roller w/Smooth Shaft(3")	30B	Spring-4"
	15B	Kicker Roller w/Threaded Shaft	30C	Spring-5"
		(4" & 5")	31	Spring End With Nut (3" & 4")
	16	Kicker Roller Retaining Clip (x2)	31-5	Spring End With Nut (5")
	17	Track Roller Bracket (2pc)	32	Spring Adjusting Bolt ½"
	18	Track Roller Shaft	32A	Spring Adjusting Bolt 5/8"
	19	Track Roller 3"	33	Spring Adjusting Bolt Washer ½"
	19A	Track Roller w/Shaft	33A	Spring Adjusting Bolt Washer 5/8"
	20	Track Roller Collar	34	Tracks 8'
	21-34	Main Spring Bracket (3" & 4")	35	Label 2.5" X 2" Warning Bracket
	21-5	Main Spring Bracket (5")		-

Types And Sizes Of Jamb Track Hardware

Part#	Description	Weight	Width	Height
SS-3	Short Set (3" spring)	350lbs	19'	6'6"-7'
SL-3	Standard Long (3" spring)	350lbs	19'	7'-7'6"
SJ-4	Standard Jumbo (4" spring)	450lbs	22'	7'-8'
HJ-5	Heavy Jumbo (5" spring)	550lbs	22'	7'-8'
HJL-5	Long Heavy Jumbo (5" spring)	650lbs	22'	8'-10'6"

All Jamb Track Hardware must be installed and maintained by technicians who are experienced and well trained

If you are not well trained and experienced, Do not try to install Jamb Track Hardware simply by reading the instructions, it can not be done.

If you seed training to install this Jamb Track Hardware, we recommend that you are taught by a well trained professional with more than five years experience installing and maintaining this exact type of hardware. Training and installing is at your own risk.

WARRANTY

All-O-Matic, Inc jamb track hardware is warranted against defects in materials and workmanship for two years. Any part or parts of hardware found to be defective within this period shall, at the manufacturer's option, be repaired or replaced free of charges, F.O.B. Our factory.

The above warranty is in lieu of all other warranties, expressed or implied, and shall be considered void if visible evidence implies, recommended installation procedures and maintenance instructions were not followed.



ALL-O-MATIC INC Van Nuys, CA 91406





Quality.

Performance.

