


JIMMYJANE

# FORM 3 PRO™

JJ10911

INSTRUCTIONAL MANUAL





# INCLUDES

- (1) FORM 3 PRO
- (1) MAGNETIC USB CHARGING CORD
- (1) STORAGE BAG

## PRODUCT FEATURES & BENEFITS

YOUR BEST-EVER ORGASMS ARE IN THE PALM OF YOUR HAND WITH THIS EXTREMELY POWERFUL, ERGONOMICALLY DESIGNED LAY-ON VIBRATOR THAT PROVIDES TOE-CURLING PLEASURE WITH PINPOINT ACCURACY. THE FORM 3 PRO'S SLEEK SHAPE IS REMINISCENT OF A TONGUE WITH A SUBTLE CURVE THAT MAKES IT EASY TO GET FULL-COVERAGE VIBRATION ON YOUR CLITORIS AND LABIA, WHILE ITS FIVE VIBRATION MODES AND INTENSITY LEVELS LET YOU CUSTOMIZE AND INTENSIFY YOUR PLAY DAY AFTER DAY.

- Bend the limber tip of the silicone touchpad to direct vibration to your sensitive areas
- Designed with super soft and flexible phthalate-free, latex-free silicone
- Choose between five high-performing vibration modes and five intensity levels
- 60 minute run-time
- Comfortable finger holder for an easy no-slip grip
- Used by women and couples
- Great for clitoral stimulation
- Waterproof; fully submergible and bath-friendly
- Magnetic USB charging cord
- Includes cloth storage bag

# INSTRUCTIONS

### POWER ON

Press and hold the power button for two-plus seconds to turn on your massager.  
Always starts at third vibration pattern.

### POWER OFF

Press and hold the power button for two-plus seconds to turn on your massager.

### MODE CYCLE INSTRUCTIONS

Press power button to cycle through the 5 pulsating patterns  
Press "+" button - power level increase  
Press "-" button - power level decrease

### SPEED/INTENSITY LEVELS



1

### VIBRATION PATTERNS

4

### FREQUENCIES

5 (1 SPEED + 4 MODES)



# PRODUCT SPECS

USB CHARGING  
LITHIUM BATTERY  
WATERPROOF  
SILICONE + STAINLESS STEEL  
INSIDE ABS

## SIZE

Length: 102mm  
Width: 45mm

## CHARGING

120 minutes

## RUN TIME

45+ minutes

## IPX RATING

IPX7 - FULLY WATERPROOF  
Protected against the effects of temporary water submersion at a depth of one meter, for 30 minutes.



# CHARGING INSTRUCTIONS

## CONNECTING MAGNETIC CHARGER

Connect the JimmyJane Magnetic USB Charging Cord to the magnetic charging points on the toy.

This product is only compatible with the JimmyJane Magnetic USB Charging Cord.

- Always ensure both points connect and do not touch any other metal item.
- Do not attempt to charge during use.
- Do not charge near water.





# CARE INSTRUCTIONS

SPRAY AN ANTIBACTERIAL CLEANER LIKE THE JIMMYJANE ANTIBACTERIAL TOY CLEANER ON YOUR MASSAGER BEFORE USE. WIPE WITH A CLEAN, DRY CLOTH AND LET IT AIR DRY. REPEAT AFTER USE AND STORE IN A COOL, DRY PLACE.



# WARNING

THIS VIBRATOR IS FOR NOVELTY PURPOSES ONLY, IS NOT INTENDED FOR THERAPEUTIC PURPOSES AND IS RECOMMENDED FOR EXTERNAL USE ONLY. PROLONGED USE FOR MORE THAN 30 MINUTES OR FREQUENT USE OF MORE THAN TWICE DAILY IS NOT ADVISED OR RECOMMENDED. THIS VIBRATOR IS INTENDED FOR ADULT USE ONLY. USE WATER-BASED LUBRICANTS ONLY.

THIS APPLIANCE IS NOT INTENDED FOR USE BY CHILDREN OR PERSONS WITH REDUCED PHYSICAL, SENSORY OR MENTAL CAPABILITIES. TO AVOID ELECTRIC SHOCK, DO NOT USE CHARGER NEAR WATER. DO NOT USE ON SWOLLEN OR INFLAMED AREAS OF SKIN. DISCONTINUE USE IF DISCOMFORT OCCURS. DO NOT USE ON NECK OR SPINE AREAS.

- Do not use with silicone lubricants because they may damage the product.
- Do not clean with products that contain alcohol, petrol, or acetone.
- Do not boil, bake, microwave, or put this product in a dishwasher since it may damage the electronic components and present a serious FIRE HAZARD.
- Do not store in extreme temperatures.
- Do not charge near water.

# MAGNETIC CHARGER WARNING

- Before charging, make sure charger is free from water or lubricant residue.
- Do not charge near water.
- Product will not charge if it is too hot (115 degrees fahrenheit/+46 degrees celsius). Once the temperature of product reaches a safe level, charging will begin automatically.

# LITHIUM BATTERY WARNING




- Rechargeable Lithium Ion batteries are potentially hazardous and can present a serious FIRE HAZARD if damaged, defective, or improperly used.

# JIMMYJANE PAIRINGS

- Magnetic USB Charging Cord
- Intimate Lubricant
- Sensation Lubricant
- Toy Lubricant
- Antibacterial Toy Cleaner

## DISPOSAL OF OLD ELECTRONIC EQUIPMENT

THE CROSSED-OUT DUSTBIN SYMBOL INDICATES THAT THIS PLEASURE OBJECT SHOULD NOT BE TREATED AS HOUSEHOLD WASTE, BUT RATHER BE BROUGHT TO THE APPROPRIATE COLLECTION POINT FOR RECYCLING OF ELECTRICAL AND ELECTRONIC EQUIPMENT.



PATENTS: [WWW.JIMMYJANE.COM/PAGES/PATENTED-TECHNOLOGIES](http://WWW.JIMMYJANE.COM/PAGES/PATENTED-TECHNOLOGIES)

WARRANTY: [WWW.JIMMYJANE.COM/PAGES/JIMMYJANE-WARRANTY](http://WWW.JIMMYJANE.COM/PAGES/JIMMYJANE-WARRANTY)



JIMMYJANE