

JIMMYJANE



# MINI CHROMA™

JJ10514 / JJ10513

INSTRUCTIONAL MANUAL





# INCLUDES

- (1) MINI CHROMA
- (1) MAGNETIC USB CHARGING CORD
- (1) STORAGE BAG
- (1) REMOTE CONTROL

# PRODUCT FEATURES & BENEFITS

JUST BECAUSE IT'S A MINI DOESN'T MEAN IT WON'T PACK A PUNCH. YOU'LL LOVE ITS PLAYFUL REMOTE THAT YOU'LL WANT TO HIDE IN THE MOST INTIMATE OF PLACES.

WITH SEVEN VIBRATION MODES AND THREE INTENSITY LEVELS, THIS WHISPER-QUIET, POWERFUL AND SAFE ALUMINUM BULLET IS THE PERFECT DISCREET ON-THE-GO VIBRATOR YOU NEED IN YOUR ROTATION.

- High-performance bullet; discreet and whisper-quiet
- Powerful, fulfilling vibrations
- Choose between seven high-performing vibration modes and three intensity levels
- Remote control to maximize couples' play
- Made with clean, safe non-porous aluminum
- Great for beginners
- Simple, intuitive controls
- Used by women, men and couples
- Waterproof; fully submergible and bath-friendly
- Magnetic USB Charging Cord
- Includes cloth storage bag
- Magnetic USB Charging Cord

# INSTRUCTIONS

## POWER ON / STANDBY MODE

Press and hold the power button for two-plus seconds until the LED light turns on to activate standby mode.

## MODE CYCLE INSTRUCTIONS

Once in standby mode, click the power button on the remote or the Mini Chroma to cycle through 10 different vibration patterns.

## POWER OFF

Press and hold remote for three seconds to turn vibration off  
(Mini Chroma will go back into "Standby" mode)

Press and hold button on Mini Chroma for three seconds to turn off completely.

## SPEED/INTENSITY LEVELS


3

## VIBRATION PATTERNS


7

## FREQUENCIES

10 (3 SPEEDS + 7 PATTERNS)



POWER/MODE BUTTON



POWER/MODE BUTTON



# PRODUCT SPECS

USB CHARGING

LITHIUM BATTERY

WATERPROOF

ALUMINUM ALLOY, SILICONE, ABS (BULLET PART ONLY)

## SIZE

Length: 78 mm

Width: 20 mm

Height: 21 mm

Diameter: 20 mm

## CHARGING

90 minutes

## RUN TIME

60 minutes

## IPX RATING

IPX7 - FULLY WATERPROOF

Protected against the effects of temporary water submersion at a depth of one meter, for 30 minutes.



# CHARGING INSTRUCTIONS

## CONNECTING MAGNETIC CHARGER

### Mini Chroma

Connect the JimmyJane Magnetic USB Charging Cord to the magnetic charging points on the toy.

### Mini Chroma Remote

Connect the JimmyJane Magnetic USB Charging Cord to the magnetic charging points on the Remote.

This product is only compatible with the JimmyJane Magnetic USB Charging Cord.

- Always ensure both points connect and do not touch any other metal item.
- Do not attempt to charge during use.
- Do not charge near water.





# CARE INSTRUCTIONS

SPRAY THE JIMMYJANE ANTIBACTERIAL CLEANER ON YOUR TOY  
BEFORE USE. WIPE WITH A CLEAN, DRY CLOTH AND LET IT AIR DRY.  
REPEAT AFTER USE AND STORE IN A COOL, DRY PLACE.



# WARNING

THIS BULLET IS NOT INTENDED FOR THERAPEUTIC PURPOSES AND IS RECOMMENDED FOR EXTERNAL USE ONLY. PROLONGED AND FREQUENT USE IS NOT ADVISED OR RECOMMENDED AS THESE ITEMS ARE SOLD FOR NOVELTY PURPOSES ONLY. THIS VIBRATOR IS INTENDED FOR ADULT USE ONLY.

THIS APPLIANCE IS NOT INTENDED FOR USE BY CHILDREN OR PERSONS WITH REDUCED PHYSICAL, SENSORY OR MENTAL CAPABILITIES. TO AVOID ELECTRIC SHOCK, DO NOT USE CHARGER NEAR WATER. DO NOT USE ON SWOLLEN OR INFLAMED AREAS OF SKIN. DISCONTINUE USE IF DISCOMFORT OCCURS. DO NOT USE ON NECK OR SPINE AREAS.

- Do not use with silicone lubricants because they may damage the product.
- Do not clean with products that contain alcohol, petrol, or acetone.
- Do not boil, bake, microwave, or put this product in a dishwasher since it may damage the electronic components and present a serious FIRE HAZARD.
- Do not store in extreme temperatures.
- Do not charge near water.

# MAGNETIC CHARGER WARNING

- Before charging, make sure charger is free from water or lubricant residue.
- Do not charge near water.
- Product will not charge if it is too hot (115 degrees fahrenheit/+46 degrees celsius).  
Once the temperature of product reaches a safe level, charging will begin automatically.

# LITHIUM BATTERY WARNING



- Rechargeable Lithium Ion batteries are potentially hazardous and can present a serious FIRE HAZARD if damaged, defective, or improperly used.

# JIMMYJANE PAIRINGS

- Mini Chroma Sleeve 1-3
- Magnetic USB Charging Cord
- Intimate Lubricant
- Sensation Lubricant
- Toy Lubricant
- Antibacterial Toy Cleaner

## DISPOSAL OF OLD ELECTRONIC EQUIPMENT

THE CROSSED-OUT DUSTBIN SYMBOL INDICATES THAT THIS PLEASURE OBJECT SHOULD NOT BE TREATED AS HOUSEHOLD WASTE, BUT RATHER BE BROUGHT TO THE APPROPRIATE COLLECTION POINT FOR RECYCLING OF ELECTRICAL AND ELECTRONIC EQUIPMENT.



PATENTS: [WWW.JIMMYJANE.COM/PAGES/PATENTED-TECHNOLOGIES](http://WWW.JIMMYJANE.COM/PAGES/PATENTED-TECHNOLOGIES)

WARRANTY: [WWW.JIMMYJANE.COM/PAGES/JIMMYJANE-WARRANTY](http://WWW.JIMMYJANE.COM/PAGES/JIMMYJANE-WARRANTY)



JIMMYJANE