

AUSTERE

Clean & Protect \\ User Guide/Owner's Manual

Model number: 3S-CP200P1, 5S-CP230P1



CAUTION Keep Clean & Protect out of the reach of children. Avoid contact with eyes. If the product gets in eyes, rinse thoroughly with water. If swallowed, drink plenty of water.

Austere Clean & Protect is the perfect solution for keeping your electronic devices and screens in pristine condition. Use on your TV, computer, tablet, cell phone, car screen, fridge screen, workout equipment screen, glasses, camera lenses, gaming consoles, and gaming accessories.

Product Registration

Prior to using your product, please go to www.austere.com/guarantee to register your product and to access our complete limited lifetime guarantee statement.

Note: Please read and follow all instructions and safety precautions carefully to ensure the best performance and protection of your electronics.

DIRECTIONS FOR USE

Cleaning your displays.

- Always turn off all electronics before cleaning and ensure the device is cool to the touch.
- Spray the solution directly on the "CLEAN" side of the provided cloth, NOT directly onto the device.
- Spraying cleaner directly on the electronics or using other materials to apply cleaner can damage your electronics and could potentially void the warranty of your devices.
- In a circular pattern, gently clean the device/screen to clear marks, dust, and debris.
- Flip the cloth over to the "POLISH" side and, again in a circular pattern, gently buff the screen to perfection.
- Only use the Austere provided Clean & Polish cloth to clean your electronics.

All Austere's Clean & Protect products are alcohol-free, ammonia-free, and allergen-free.

Application Usage:

- Do not spray the cleaner directly on your devices, spray onto the cloth.
- Ensure your device is off and cooled down before usage to prevent damage.
- Do not spray the cleaner directly onto sensitive surfaces such as painted or varnished surfaces, wooden furniture, or delicate fabrics.
- Do not mix with other cleaning products to ensure the integrity of the solution. Also, do not dilute the solution with water.
- Do not use on damaged screens.
- Before using the cleaner on your electronic screen, it is advisable to test it on a small, inconspicuous area first to ensure compatibility and avoid any potential damage.

Cleaning and care for your dual-sided microfiber cloth.

- It is important to wash the cloth after every use as it collects dirt and dust, which could scratch screens if used without washing.
- Simply hand or machine wash the microfiber cloth with warm water only.
- Once washing is complete, remove the cloth and air dry.
- Do not machine dry, as it will damage the cloth.

Safety:

- Keep Clean & Protect out of the reach of children and pets.
- Avoid contact with eyes. Rinse thoroughly with water if necessary.
- Do not Swallow.
- Wash hands after usage.

Limited Lifetime Guarantee Applies to the following:

- Performance of the spray and the dual-sided Clean & Polish cloth.
- Defects in materials and workmanship under normal use and conditions.

Limited Lifetime Guarantee does not cover damage or defects resulting from:

- Improper use or misuse of the product and/or cloth.
- Accidents, negligence, or unauthorized repairs or alterations.
- Normal wear and tear of the Clean & Polish cloth.
- Exposure to extreme temperatures in the storage of the product.
- Failure to follow care and maintenance instructions provided by Austere.

Technical Support: Please contact our technical support team with installation questions, troubleshooting needs, or general product questions.

- Phone: 1-855-672-0684
- Email: support@austere.com

Find all documents for Limited Lifetime Guarantee at [Austere.com](https://www.austere.com).



2023 Austere. All rights reserved. Austere and More Than Expected are trademarks of Austere or its affiliates. All other trademarks are the property of their respective owners.