


# AURORA SERIES QUICK START GUIDE


SIONYX Aurora Low-Light Camera

## CAMERA SETUP


1. Pull latch down to remove viewfinder and access the battery compartment




2. Install battery and Micro SD card




3. Re-install viewfinder into the camera




4. Be sure the camera is set to OFF



5. Connect to the USB port by lifting rubber flap and charge camera



6. Turn camera ON to any mode



OVER to camera setup continued



SIONYX


www.sionyx.com

## CAMERA SETUP CONTINUED


7. Download SIONYX Aurora App from App Store or Google Play




8. Look into the viewfinder and rotate the diopter to bring the menu into focus. Your camera is now ready to use



9. Rotate selector ring to change between daytime, twilight, and night-mode



10. Additional settings can be viewed and accessed by long pressing SET on the top of the camera



### NOTE:

Aurora Sport and Black models ship with Electronic Viewfinder Display Timeout set to 60 seconds to conserve battery when not in use. To disable, access second layer menu.

100  
Cumings  
Center

Beverly, MA  
01915 USA

**SIONYX**

[www.sionyx.com](http://www.sionyx.com)

PN: 1AG6P1P7347--  
Made in Indonesia