



Step 1Turn up the edge of the grip.



Step 2Put the grip on the joystick, fall the edge of the grip.



Step 3Rotate the grip until the edge wrap up the joystick.



Wrong
The grip does not wrap the joystick completely. The grip may go off easily while you playing games.



Correct
The grip wrap up the joystick completely.

Note:

If the grips become slippery, please clean them with medical alcohol or detergent.