

Professional Foam Party Products

Call with questions 1-888-731-4415 at any time or email <u>infofoamdaddy@gmail.com</u>

HD Stacker Foam Cannon Setup Operation

- Attach stand bracket to Cannon by removing one rubber footing to be able to slide Bolt through holes on square bracket already attached to the cannon, replace the rubber footing and tighten. (You don't have to take it off during breakdown, you can leave it on)
- Set-up Tripod.
- Lift Machine and slide onto Tripod.
- Attach standard garden hose from Foam Cannon Machine to submersible pump and place pump inside your 50-gallon drum/large garbage can.
- Add 40 gallon of water and 3/4 of a gallon of foam solution
- Plug both your machine and pump into a surge protector and turn on.
- Baffler plate included. While fan is on, place baffler on the back grate of the machine to

control air flow, this gives you more control over foam production. The plate will suction to the grate while the machine is on.

You will need one standard garden hose, two 5-gallon buckets with lids and a 50-gallon drum/large garbage can.

WARNING: DO NOT let foam run backwards into fan unit. Tilt the flow away from fan. Only use potable city water/ tap water. Pond or lake water can affect production of foam due to lack of minerals in water.