Please read the instructions carefully before using this lamp Your pendant light should be installed by a qualified electrician



Please ensure to switch off all power to the electrical components being worked on.

Installation of the lamp

1. Wire up the E26 fitting with the provided cable, see Figure 1.

2. The wooden pendant can now be threaded over the wire to sit on top of the E26 Fitting, see Figure 2.

3. The cable can now be inserted into the Ceiling rose, slide the ceiling rose up or down the cable until you have the correct drop length suitable for your space. Once you have the correct drop length tighten the cord grip fully from the inside of the ceiling rose.

4. You can now cut off the excess cord ensuring you leave enough cord left to make electrical connections.

5. Attach the metal crossbar to the ceiling using supplied steel screws.

6. Make the appropriate electrical connections. The black wire is live, the white is neutral and the green is earth.

7. Once all electrical connections are complete, the connections and wires can be pushed into the ceiling cavity or remain within the ceiling rose.

8. The ceiling rose can now be screwed into the crossbar with the 2 x M4 screws provided.

9. Ensure the lamp holder is sitting fully inside the wooden cap, now unscrew the shade ring and thread the lamp holder through the ceramic shade and then through the smaller wooden ring, see Figure 3. Reattach the shade ring to secure the shade and wooden ring in place.

10. The metal shade ring should be screwed onto the lamp holder, just enough for it to be held on securely but not all the way up the thread, see Figure 4.

11. With everything switched off you can now screw in your E26 light bulb Max 25W (not included)

Maintenance and Care

Before replacing a bulb turn off the light at the switch and let the bulb cool down for at least 10 minutes

- 1. Only change the bulb if it has completely cooled down. Use a clean cloth to help replace the bulb.
- 2. If necessary the pendant light can be cleaned using a slightly damp cloth. Do not immerse in water.

3. The pendant light is designed for indoor use only.

4. If the external flexible cable or cord is damaged it shall be replaced by a qualified electrician in order to avoid a hazard.

5. Young children should be supervised at all times to ensure they do not play with appliances

6. Position the cord so it will not become a hazard.

Technical Specifications

- Voltage 120V-60Hz
 Rated Power 25W Max
- E26 Max 25W bulb
- Cable length: Approx. 1.5m
- Wooden Caps and Ceiling Rose

Dawn Pendant Light North America - DP01NA



