Element Pendant Light - EP01

Please read the instructions carefully before using this lamp Your pendant light should be installed by a qualified electrition



Please ensure to switch off all power to the electrical components being worked on.

Installation of the lamp.

- 1. Switch off electricity supply. Before making any electrical connections ensure the following parts are connected/slotted onto the provided cable in the following order: metal lamp holder, Oak cap upper, ceiling rose (including cord grip assembly).
- 2. Slide the ceiling rose up and down the cable until you have the correct drop length suitable for your space. Once you have the correct drop length tighten the cord grip fully from the inside of the ceiling rose. You can now cut off the excess cord ensuring you leave enough cord left to make electrical connections.
- 3. Attach the metal crossbar to the ceiling using supplied 4x40mm screws and plugs.
- 4.. Using the terminal block provided make the appropriate electrical connections. The brown wire is live, the blue is neutral and the yellow and green is earth.
- 5. The metal lamp holder and metal crossbar must be earthed.
- 6. Once all electrical connections are complete the connections and wires can be pushed into the ceiling cavity or remain within the ceiling rose.
- 7. The ceiling rose can now be screwed into the crossbar with the 2 x m3 screws provided.
- 8. Ensure the lamp holder is sitting partially inside the Oak cap upper part, remove the shade ring and slide on the ceramic shade first, then the Oak cap lower part, thread the shade ring on enough for it to be held on securely but not all the way up the thread. Ensure the Oak cap upper and Oak cap lower are interlocked with the ceramic shade inbetween.
- 10. With everything switched off you can now screw in your E27 light bulb Max 25W (not included)

Maintenance and Care

Before replacing a defective bulb turn off the light at the swtich and let the bulb cool down for at least 10 minutes

- 1. Only change the bulb if it has completely cooled down. Use a clean cloth to help replace the bulb.
- 2. If necessary the pendant light can be cleaned using a slightly damp cloth. Do not immerse in water.
- 3. The pendant light is designed for indoor use only.
- 4. If the external flexible cable or cord is damaged it shall be replaced by a qualified electrition in order to avoid a hazard.
- 5. Young children should be supervided at all times to ensure they do not play with appliances
- 6. Position the cord so it will not become a hazard.

Technical Specifications.

- Voltage 220-240V-50Hz
- Rated Power 25W Max
- E27 Max 25W bulb (do not touch the bulb with bare hands)
- Cord length : Approx 1.5m
- Wooden Cap and Ceiling Rose
- Ceramic Lampshade, Metal lampholder





