
F



Goodman Floor Lamp Item # TOB1536

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALLDO NOT OVEER TIGHTEN.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

- 1.
- Carefully remove all parts from the carton. Screw lamp pole (G) onto the top nipple of lamp base (H). Thread balancing arm (A) into side opening of part (B). Screw finial (D) onto the top nipple of shade (E). Insert light bulb (not included) into the socket. Remove plastic cover (J) from electrical plug (I). 2.
- З.
- 4.
- 5.
- 6.
- 7. Plug lamp into wall outlet.

TO ADJUST:

- 1. Loosen adjustment knob (F), pull the upper pole up or push the upper pole down to the desired height.
- 2. Tighten the adjustment knob (F).

OR

- Loosen adjustment key (C), swing the lamp arm to the desired position. 1.
- Tighten the adjustment key (C). 2.

***Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.



