



Model	OEM Replacement Parts	Applicable Accessories	Upgrade Parts	Cross Fit Compatibility
RMH1	R6WHL/RT/O (Rear Wheel) RWNGBLT1 (wingbolt w/spring) RPPK1 (Washers, cotter pin pack, all models) RLPB (Snap Button)	RCH1 (Headphone/Cable rack) RLSH1 (Laptop Shelf) RBCB (Flex Straps)		
R2RT	R4CSTR/Y/B (Caster wheels) R6WHL/RT/O (Rear Wheels) RWNGBLT1 (wingbolt w/spring) RHDWR2 (R2RT Parts Pack) R2TAPE (Skid Tape for R2RT) RH2 (R2RT replacement Handles) RLPB (Snap Button) RPPK1 (Washers, cotter pin pack, all models)	RSD2 (R2RT Deck system) RSH2 (R2RT Deck System) R2SSH (R2RT Quick Shelf) R2LSH (R2RT Long Shelf) RRSA (Flex Strap Anchor System) RCH1 (Headphone/Cable rack) RLSH1 (Laptop Shelf) RBCB (Flex Straps)		
R6RT	R4CSTR/Y/B (Caster wheels) R8WHL/RT/O (8" x 2.5" Rear Wheels) RWNGBLT1 (wingbolt w/spring) RHDWR6 (R6RT Parts Pack) R6TAPE (Skid Tape for R6RT) RH6 (R6RT Replacement Handles) RLPB (Snap Button) RPPK1 (Washers, cotter pin pack, all models)	RSD6 (R6RT Deck System) RSH6 (R6RT Shelf System) RRK1 (Cargo extention rack) RRSA (Flex Strap Anchor System) RCH1 (Headphone/Cable rack) RLSH1 (Laptop Shelf) RBCB (Flex Straps)	R8X3WHL/O (8 x 3" All Terrain Rear Wheel)	
R6G	R5X2CSTR (5 x 2" All Terrain Caster w/brake)) R8X3WHL/O (8 x 3" All Terrain Rear Wheel) RWNGBLT1 (wingbolt w/spring) RHDWR6 (R6RT Parts Pack) R6TAPE (Skid Tape for R6RT) RH6 (R6RT Replacement Handles) RLPB (Snap Button) RPPK1 (Washers, cotter pin pack, all models)	RSD6 (R6RT Deck System) RSH6 (R6RT Shelf System) RRK1 (Cargo extention rack, fo R6RT, R6G, R8, R10, R12) RRSA (Flex Strap Anchor System) RCH1 (Headphone/Cable rack) RLSH1 (Laptop Shelf) RBCB (Flex Straps)		R5CSTR/Y/B R8WHL/RT/O (8" x 2.5" Rear Wheels)
R8RT	R5CSTR/Y/B (5 x 1.25" Cater Wheel w/brake) R8WHL/RT/O (8 x 2.5" Rear Wheel) RWNGBLT1 (wingbolt w/spring) RHDWR8 (R8RT Parts Pack) R8TAPE (Skid Tape for R8RT) RH10 (R8, R10, R12RT Replacement Handles) RLPB (Snap Button) RPPK1 (Washers, cotter pin pack, all models)	RSD10 (R8, R10, 12RT Deck System) RSH10 (R8, R10, R12RT Shelf System) RRK1 (Cargo extention rack, fo R6RT, R6G, R8, R10, R12) RRSA (Flex Strap Anchor System) RCH1 (Headphone/Cable rack) RLSH1 (Laptop Shelf) RBCB (Flex Straps) RSH10Q (R8, R10, R12RT Quick Shelf System) RSHM2 (2 Tier Shelf System)	R5X2CSTR (All Terrain Upgrade Wheels) R8X3WHL/O (8 x 3" All Terrain Rear Wheel)	

R10RT	R5CSTR/Y/B (5 x 1.25" Cater Wheel w/brake) R10WHL/RT/O (10 x 3" Rear Wheel) RWNGBLT1 (wingbolt w/spring) RHDWR10 (R10RT Parts Pack) R10TAPE (Skid Tape for R8, R10, R12RT, R14RT, R16RT, R18RT) RH10 (R8, R10, R12RT Replacement Handles) RLPB (Snap Button) RPPK1 (Washers, cotter pin pack, all models)	RSD10 (R8, R10, 12RT Deck System) RSH10 (R8, R10, R12RT Shelf System) RRK1 (Cargo extention rack, fo R6RT, R6G, R8, R10, R12) RRSA (Flex Strap Anchor System) RCH1 (Headphone/Cable rack) RLSH1 (Laptop Shelf) RBCB (Flex Straps) RSH10Q (R8, R10, R12RT Quick Shelf System) RSHM2 (2 Tier Shelf System)	R5X2CSTR (All Terrain Upgrade Wheels)	
R12RT	R8CSTR/RT (8 x 2.5" All Terrain Caster) R10WHL/RT/O (10 x 3" Rear Wheel) RWNGBLT1 (wingbolt w/spring) RHDWR12 (R12RT Parts Pack) R10TAPE (Skid Tape for R8, R10, R12RT, R14RT, R16RT, R18RT) RH10 (R8, R10, R12RT Replacement Handles) RLPB (Snap Button) RPPK1 (Washers, cotter pin pack, all models)	RSD10 (R8, R10, 12RT Deck System) RSH10 (R8, R10, R12RT Shelf System) RRK1 (Cargo extention rack, fo R6RT, R6G, R8, R10, R12) RRSA (Flex Strap Anchor System) RCH1 (Headphone/Cable rack) RLSH1 (Laptop Shelf) RBCB (Flex Straps) RSH10Q (R8, R10, R12RT Quick Shelf System) RSHM2 (2 Tier Shelf System)		R8CSTR/RT (8 x 3" All Terrain Caster)
R14G	R6X3CSTR (6 x3" All Terrain Caster) R8WHL/RT/O (8 x 2.5" Rear Wheels) RPPK1 (Washers, cotter pin pack, all models) R10TAPE (Skid Tape for R8, R10, R12RT, R14RT, R16RT, R18RT)	RRSA (Flex Strap Anchor System) RCH1 (Headphone/Cable rack) RLSH1 (Laptop Shelf) RBCB (Flex Straps)	R8X3WHL/O (8 x 3" All Terrain Rear Wheel)	
R16RT	R6X3CSTR (6 x3" All Terrain Caster) R8X3WHL/O (8 x3" Rear Wheel) RPPK1 (Washers, cotter pin pack, all models) R10TAPE (Skid Tape for R8, R10, R12RT, R14RT, R16RT, R18RT)	RRSA (Flex Strap Anchor System) RCH1 (Headphone/Cable rack) RLSH1 (Laptop Shelf) RBCB (Flex Straps)		
R18RT	R8CSTR/RT (8 x 3" All Terrain Caster) R10WHL/RT/O (10 x 3" Rear Wheel) RPPK1 (Washers, cotter pin pack, all models) R10TAPE (Skid Tape for R8, R10, R12RT, R14RT, R16RT, R18RT)	RRSA (Flex Strap Anchor System) RCH1 (Headphone/Cable rack) RLSH1 (Laptop Shelf) RBCB (Flex Straps)		R8CSTR/RT (8 x 2.5" All Terrain Caster)