








**ITEM NAME / NOM D'ITEM: ELLEN DINING CHAIR**


**ITEM #/NO. ITEM: 101952/101953**

**PART LIST / LISTE DES PIÈCES**


(1)	(2)	(3)	(4)
 <p style="text-align: right;">x1</p>	 <p style="text-align: right;">x1</p>	 <p style="text-align: right;">x1</p>	<p>A.  M6 x 25mm x4</p> <p>B.  M6 x 30mm x2</p> <p>C.  5mm x1</p> <p>D.  6mm x1</p>

**ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE**

I.



II.



For missing parts or damaged parts, please call

USA : 1-866-798-6663

Canada : 514-382-6661