

Mini Pump Gold Starter Contact Points



If your Mini Pump only hums but the fan spins freely, clean the debris off the Gold Starter Contact Points. (See the photos below) These points can be found near the inside back behind the Power Cord entry.

The third vent hole is directly over these points. With the power cord unplugged, take a spray nozzle with compressed air and insert it into the second vent hole to blow the debris of the contacts. This is 99% of the time the issue when the pump spins freely but only hums when plugged in.

