

IMPORTANT RECOMMENDATIONS FOR INSTALLATION

Installation should comply to AS/NZS3500.1 2003 or relevant local requirement.
Not suitable for gravity feed application.
Hot & cold water inlet pressures should be equal.



WATER PRESSURE

Operating static pressure is 150 - 500kpa. If pressure exceeds this, then an approved pressure limiting valve must be installed.



PRE-FLUSH

Always flush out the pipework before connecting any faucets.
Damage caused to the faucet by debris coming through the pipework is not covered under warranty.



WATER TEMPERATURE

Maximum hot water temperature is 75 degree.

CITY LIFE INSTALLATION INSTRUCTION CL.5000



IMPORTANT!

Please read this instruction **Prior** to installation



ATTENTION!

Failure to do so will void the warranty.



T 1300 837 688 E info@verotti.com
www.verotti.com

Installation

1. Ensure both supply pipes have been flushed and are free from debris before proceeding.
2. Ensure the top and bottom rail mounts are fixed securely to a solid substrate best prepared prior to lining the shower enclosure wall. Follow the assembly diagram according to the model you have purchased.
3. With the rubber gasket in place, hand tighten the 'tapered' nut end of the hose to the hand shower and the other end to the outlet connection. The hose should hang naturally without unnecessary kinks or tight radius bends.
4. Turn water supply on and check carefully all connection points for water tightness.

Care and Use

1. Shutting the tap gently will reduce the chance of water hammer or 'banging' pipes.
2. Regularly clean the chrome surfaces only with non scouring, neutral wash solutions.

