IMPORTANT RECOMMENDATIONS FOR INSTALLATION

Installation should comply to AS/NZS3500.1 2003 or relevant local requirement. Not suitable for gravity feed application.

Hot & cold water inlet pressures should be equal.



WATER PRESSURE

Operating static pressure is 150 - 500kpa. If pressure exceeds this, then an approved pressure limiting valve must be installed.



PRE-FLUSH

Always flush out the pipework before connecting any faucets. Damage caused to the faucet by debris coming through the pipework is not covered under warranty.



WATER TEMPERATURE

Maximum hot water temperature is 75 degree.



ATTENTION!

Failure to do so will void the warranty.



CITY LIFE INSTALLATION INSTRUCTION CL.5100







IMPORTANT!


Please read this instruction **Prior** to installation





ATTENTION: For the slider, please adjust the inside white device to the very middle place before putting it into the rail.

















Chrome plated surfaces should be cleaned with mild liquid detergent or soap and water. Do not use cream cleaners, as they are abrasive.

Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.